Operation manual Wood chip boiler ECO-HK 20-60kW



Exactly read, follow and save these instructions

HARGASSNER Heating technology for *Biomass* A 4952 Weng, Upper Austria Phone: +43/7723/5274-0 Fax: +43/7723/5274-5 office@hargassner.at www.hargassner.com

Foreword

Chapter I: Technical data

1 Type plate and CE-conformity2 Dimensions.3 Intended purpose.4 Fuel quality.5 Construction of the boiler room:6 Construction of the fuel storage room:7 Execution of heating circuits8 Back end protection9 Flue pipe - chimney dimensions10 Electrical connection	-4 -4 -5 -6 -6 -7 -7
Chapter II: Safety regulations	
1 General safety advices II 2 Remaining risks II	-8 -9
Chapter IV: Boiler construction	
1 Overview of components IV	-11
Chapter V: Control	
1 Layout of the control V 2 Operation modes V 3 Status indication of the boiler: V 4 Menu tree - Info V 5 Customer settings V 6 Optional remote controls FR35 / FR40 (digital) V and FR25 (analogue) V	-12 -14 -15 -17 -21
Chapter VI: Commissioning	
1 Checks prior commissioning	-28 -28
Chapter VII: Operation	
1 Safety instructions.VII2 Start-up boiler for the first timeVII3 Settings recirculation (optionally)VII4 Inspections prior starting up the boilerVII	-29 -30 -30 -30
Kapitel VIII: Cleaning, Maintenance	
1 Cleaning intervals VIII	-32
Chapter IX: Troubleshooting	
1 Errors IX 2 List of errors IX	-35 -36
Chapter X: Parameters	
1Parameters Manual operation levelX2Installer levelX3Parameter list - CustomerX4Parameter list - InstallerX5Parameter list - ServiceX6Parameter - Setup /data loggingX	-45 -49 -55 -57 -59 -63
Chapter XI: Appendix	
7 Copyright notice XI	-64



Foreword

Dear customer!

The AUTOMATIC WOODBIOMASS BOILER from HARGASSNER GmbH is a state of the art product and is manufactured to latest productions standards.

Keep this operation manual available inside the boiler door .

The operation manual includes:

- getting introduced to the boiler
- and how to use this boiler according to its determination

This operation manual contains important hints, to operate the boiler

- safely
- appropriate
- and economically

The observance of this manual helps:

- Avoiding risks
- · Reduction of reparation costs and downtimes
- Enhance the reliability and the boiler life time

Additionally to this operation manual you find:

- Installation manual of the boiler
- · Wiring diagram and sensor overview of the boiler
- Hydraulic schemes
- · Installation protocol and commissioning checklist
- Safety sticker for the fuel storage room



2 Dimensions

Dimensions in (...) are for ECO-HK 40 - 60



Term	Description	Value	Unit
В	Total width	660 (745)	[mm]
Т	Total depth	1220 (1310)	[mm]
Н	Total height incl. Touch display	1455 1550	[mm]
	Total weight	490 (560)	[kg]

3 Intended purpose

The AUTOMATIC BIOMASS BOILER is designed to heat up water only. The only fuels allowed for this boiler are those, which are separately defined by Hargassner GmbH. Use the boiler in technically safe condition only. Rectify errors immediately.

The appropriate operation also covers observation of all items of this operation manual and the carrying out of inspection- and maintenance works.

I Technical data

4 Fuel quality

use fuels according to EN 14961 only

	CAUTION
\land	 use Hargassner GmbH released and permitted fuels only! if using other fuels, it is absolutely necessary to have consultation by Hargassner GmbH. Have feasibility evaluated by Hargassner GmbH

4.1 Wood chips (B1)

For proper extraction of the fuel storage room and to ensure perfect combustion, use Wood chips, Class **B1** according to **ÖNORM EN 14961- 4:2011** only.

- Water content M10 M35
- Size P16(A/B) P31.5

4.2 Wood Pellets (A1)

Ensure quality standards, when wood pellets are ordered and delivered. Quality criteria:

- least possible dust content
- hard and shiny surface of wood pellets
- 100% natural wood, no additives, etc.
- Wood pellet class A1 according to ÖNORM EN 14961-2

Calorific value	Density	Diameter	Length	Fine dust content	
4.4 - 5.3 kWh/kg	600 kg/m³	6 ±1 mm	3.15-40 mm	< 1%	

4.3 Miscanthus (E)

For non-woody fuels like Miscanthus, also ensure quality standards. Quality criteria:

- lowest possible dust-/foreign objects rate
- not additives, etc.
- Fuel class E according to ÖNORM EN 14961-1
- Size P16(A/B) P31.5

4.4 Inadmissible fuels

- Fuels with water content >35%
 - ✤ Formation of condensate
 - Increased risk of corrosion of the boiler
- · Saw dust, grinding dust
- Paper / Cardboard
- Chip boards, impregnated timber
- Black coal, brown coal or lignite
- Waste
- Plastics



5 Construction of the boiler room:

Boiler room must executed according to legislation in your country.

- ⇒ Siehe Montageanleitung "Ausführungen des Heizraumes"
- Keep air openings of the boiler free.
- Do not store any flammable materials in the boiler room.
- Execute the boiler room in frost-proof condition.
- fireproof, plane and solid floor- and ceiling construction
- Correctly install heating main switch according to authorised electrician (depending on building regulations).
- Fire extinguisher
- ⇒ Siehe Montageanleitung "Feuerlöscher"

6 Construction of the fuel storage room:

Boiler room must executed according to legislation in your country.

- No electrical installation or devices inside the storage room; all lines to be installed concealed.
- Watch for sound insulation at the wall opening for the extraction auger (transmission of structure-borne sound)
- Protection against moisture, water and dust.



Dust explosion in fuel storage room

Burning through explosive and flammable dust (sawdust).

- No motors in the fuel storage room
 except agricultural buildings
- No other source of ignition (e.g. light) in the storage room
- No electrical equipment (e.g. light switch) in the storage room
- No welding works in dusty environment

7 Execution of heating circuits

A proper execution of the heating circuits is essential for optimum operation of the boiler.

⇒ See enclosed hydraulic schemes

The design of accumulators, pumps and mixing valves has to be carried out according to legislation and through a heating professional.

8 Back end protection

If the temperature in the return is below the set value in the control an admixture of flow water takes place.

The installation of a back end protection for the correct operation is mandatory. ⇒ Siehe Montageanleitung "Rücklaufanhebegruppe"





Technical data

9 Flue pipe - chimney dimensions

⇒ Siehe Montageanleitung "Kaminanschluss - Rauchrohr"

KESSEL TYPE	NENN WÄRME LEISTUNG	ABGAS TEMP.	CO2	MASSEN- STROM	notwendiger Förderdruck	KAMINZUG max. Begrenzung	RA-DM	WASSERS WIDERS dT 10°	SEITIGER STAND dT 20°
	ĸw	°C	%	KG/S	Pa	Ра	m	mbar	mbar
					6				
ECO-HK 20	20,00	140	14	0,0104	5	10	0,150	22,6	5,9
ECO-HK 30	32,00	150	14	0,0154	5	10	0,150	49,8	13,0
ECO-HK 35	35,00	160	14	0,0180	5	10	0,150	67,0	17,5
ECO-HK 40	40,00	140	14	0,0205	5	10	0,150	80,1	20,9
ECO-HK 50	49,00	150	14	0,0235	5	10	0,150	118,8	31,0
ECO-HK 60	60,00	160	14	0,0309	5	10	0,150	173,7	46,0

10 Electrical connection

- ⇒ Siehe Montageanleitung "Elektrische Installationen"
- ⇒ See according to electrical schematics

Electrical energy	Characteristics	Unit
Voltage	400	[V] ±5%
Frequency	50	[Hz] ±5%
Fuse	13	[A]
Power consumption	100 (170)	[W]

Dimensions in (...) are for ECO-HK 40 - 60

- the electrical connection has to be executed according to the enclosed electrowiring diagram through a licensed and authorised electrician
- Main power switch outside of the boiler room (acc. to building regulations)
- max. back-up fuse 13 A (C-Character)
- · capable main switch
- It is absolutely imperative that the intrinsically safe cables are permanently installed
 - appropriate mechanical components must be selected and used
- in-phase connection L and N (see wiring diagramm)
- · Connect potential equalisation
- use highly flexible leads (e.g. H05VV-F)

Chapter II: Safety regulations

1 General safety advices

1.1 Obligation to instruct, external personnel, children

DANGER
Non-observance of the safety regulations!
 Death, injury, damage through inappropriate installation. Observe safety instructions of the boiler and in the operation manual! Exactly read the user manual PRIOR commissioning. The cladding door is a storage compartment.
External, not authorised people
 Death, injury, damage through inappropriate installation. Works on the boiler through qualified and experienced personnel only. Determine boiler supervisor.
 Keep out external, not authorised and not trained people from the boiler room and the storage room. No transfer of control entry codes. Observe legal minimum age of personnel.
• Place prohibition sign in front of boller room door and fuel storage door.

Works on electrical equipment may only be carried out through

- an professional electrician
- according to electrical standards.

Work on hydraulic systems must be carried out only by personnel with specialised knowledge and experience in hydraulics!

1.2 Special measures prior commissioning through the operator

- Licensing requirements for safe operation and accident prevention regulations must be observed!
- Do execute verifications prior first start up.
 ⇒ see "Checks prior commissioning" on page 28.
- Do execute verifications prior commissioning.
 - \Rightarrow see "Inspections prior starting up the boiler" on page 30.

DANGER

1.3 Key issuing



Unauthorised commissioning!

Commissioning through Hargassner authorised staff only.

- Prevent unauthorised commissioning.
 - Blockmainpower switch and keep keys safe.



2 Remaining risks

II

If the boiler is operated appropriately and professionally the following remaining risks must be observed:

	D A N G E R
	Hot surfaces, hot ash!
	 Burns through hot boiler components Prior any maintenance works Shut down and cool down boiler. Do not grasp into the boiler during operation. Wear heat resistant gloves. The ash in the ash box does save heat. Do not empty hot ash into dustbin. Put ash in closed, not-flammable vessels only.
	Hot water
	 Scalds through sprinkling, hot water. Check hoses, lines and connections periodically for leakages, wear and tear or any other damage! Rectify damages immediately. Prior any maintenance works on the circulation water system, de-pressurise the unit Check, if all valves are in correct position.
	DANGER
	Dust explosion in fuel storage room Burning through explosive and flammable dust (Pellet dust). • No motors in the fuel storage room (acc. to country-specific regulations) @ except agricultural buildings
	 No other source of ignition (e.g. light) in the storage room No electrical equipment (e.g. light switch) in the storage room No welding works in dusty environment
	D A N G E R
$\mathbf{\Lambda}$	Risk of deflagration, explosion and burning
	 Burns through explosively combustion of residual gases (CO) in the combustion chamber. Open combustion door carefully



II

	D A N G E R
	Rotating augers and moving parts in the area of the ash extraction, stoker auger and the fuel extraction!
	 Amputation, crushing of hands through touching moving parts or augers. Omit access to augers or motors at operating boiler. Do not perform any works on the plant, if any other person is in the danger zone. Secure / lock fuel storage room Remove blockages and perform cleaning only with tools and at switched-off boiler status. Also lock <mainpower switch="">.</mainpower> Unpredictable operation conditions The spring blades of the agitator system are retracted under the cover disc if the storage room is filled completely. These springs may shoot up suddenly. Watch out for the spring position when entering the fuel storage room. Remove fuel bridges with rods or shovels only Wear safety shoes Observe fuel storage room sticker!
	D A N G E R
	 Works on the control Touching open or free terminals, cables and equipment components can lead to severe injury or death! Oberserve information signs. Prior any works:
	D A N G E R
Λ	Flue gases in the boiler room / building
×	 Flue gases can lead to serious poisoning Check boiler doors and seals ⇒ see "Cleaning intervals" on page 32. Burning creosote-treated wood (Paint, varnish, impregnation) results in toxic ash. <i>∞</i> Avoid skin and eye contact.
	CAUTION
	Manual mode
	 Unpredictable operation conditions During manual mode no monitoring of limit switches or motors is performed. Reverse operation of augers max. 2 [Sec.] Manual mode is only allowed to be executed by trained staff.



Chapter IV: Boiler construction Overview of components



Pos	Description
1	Boiler door
2	Combustion door
3	Ignition
4	Firebed monitoring
5	Double rotary step grate
6	Ash auger
7	Refractory
8	Lambda sensor
9	Turbulators
10	Cleaning lid
11	Exhaust fan
12	Flue gas sensor
13	Recirculation
14	Ashbox (Suction cleaning optionally)
15	Control unit
16	Flame concentration jet

The boiler unit consists of the combustion chamber and the heat exchanger and controls the combustion air with air flaps and the exhaust fan.

The lambda sensor consistently monitors the flue gases. The integrated sensors monitor the temperatures of the boiler and flue gases. The turbulators clean the heat exchanger through a rod. With the all new developed de-ash system, the boiler cleans itself at regular intervals. The ash extraction auger transports the fly ash, as well as the grate ash into the completely integrated ash box. Optionally a suction system into a 300 Litre ash bin is available for the ash. The ignition of the pellets takes place through the high-efficient automatic

ignition (300 W).

1.1 Function

- Fuel transport from the storage room
- Transport into the combustion chamber
- Ignition and combustion of the fuel
- Control of energy transfer to the water based system
- Cleaning of the boiler and the ash extraction into the box
- Evacuation of the flue gases

1.1.1 Operating modes

- Automatic operation
- HWS operation
- Manual mode
- · OFF (Frost protection and residual heat use activated)



1

Chapter V: Control



1

DANGER

Wrong operation of the control!

- Risk of injury, damage of the boiler through unpredictable operation mode.
- Operation of the control through trained staff only.
- Access to all functions of the control is protected through Codes in the control. Service level and installer level.
 - Codes may not be forwarded to not authorised staff.

Layout of the control

- The categorisation of the control is divided in:
 - Display of current information about the boiler system
 - ⇒ Menu see "Standard menu" on page 13.
 - ⇒ Menu see "Menu tree Info" on page 17.
 - Settings through the customer
 - ⇒ Menu see "Customer settings" on page 21.
 - Settings through the installer at commissioning ⇒ Menu see "Installer level" on page 49.
 - Settings through Hargassner service staff only ⇒ Menu see "Parameter list - Customer" on page 55.

1.1 **Touch-Screen**, control unit

The control unit is executed through a Touch screen

- Handling through finger pressure on the display.
- **G** Scrolling in the menu through



<Standard>

- For a better understanding the menu commands are placed within the <arrows>
- Back to the previous menu with
- Back to the standard menu at any time with <Standard>. <Standard>. (eventually press 2 times)
- Activate the desired operation mode with selector switch <Function>.
- Activate input field through pressing. Display of values in "red" colour
- **Change the active values:**
 - ♦ Values flash "red"



- Enter, save or change of a value through with (SAVE).
- Short cuts to customer parameters through pressing to the according graphic in the standard menu.
 - @ possible at: Boiler-, Accumulator-, HWS-, External boiler and heating circuit - graphics



1.2 Standard menu



Pos	Description	Function		
1	Boiler temperature	Display of the current boiler temperature		
2	Boiler- flue gas temperature	Display of the current flue gas temperature		
3	Boiler- Output	Display of the current boiler temperature		
4	Status display of the boiler	\Rightarrow see "Status indication of the boiler:" on page 15.		
5	Status display of the control Display of the current menu name	 Description of the active menu Error (red flashing) ⇒ see "List of errors" on page 36. Current position in menu tree Boiler STOP in days ☞ Operation of boiler without correct ID-card 		
6	Temperature display in accumulator (<i>if available</i>) Display accumulator filling volume in [%]	Current temperatures (top, mid, bottom) of accumulator sensors currently filled heat capacity		
7	Temperature display in HWS	Display of the current water temperature in the HWS		
8	Status display of heating circuits	 OFF Heating circuits switched off Sun - Heating circuits in day mode Moon - Heating circuits in reduced mode Frost - Heating circuits in frost protection mode 		
9	Display of outside temperature	Outside temperature measured at outside sensor		
10	1 Info	Display of add. text for active function (if available)		
11	Settings	Change to customer, installer or service level or setup menu.		
12	Standard	Display of standard menu. Before every menu, a switch to the standard menu is possible. After 10 minutes of no activity, the display switches back to "Standard"		
13	Function Function	Choose operation mode of the boiler. ⇒ see "Operation modes" on page 14.		
14	Pump	Operation mode of pump: green: Pump runs; white: Pump stop		
15	Info	Change to the Info-Level		
16	Customer	Change to the Customer-Level		
17	Chimney sweep	Through pressing the Chimney sweep-Button, a special programme is started to measure the flue gas consistency.		
18	External boiler	Status display of external boiler (if available) green: released; white: locked		



2	Operation modes		
		Choose operation mode of the boiler	
• (• • •	□ S Off Function Function Function HWS Function Function Function Function	
2.1	Automatic	 Auto> (for Winteroperation for heating and domestic hot water) Control: Boiler, Accumulator, Heating circuits, HWS additional control of the heating circuits with remote control see "Optional remote controls FR35 / FR40 (digital) and FR25 (analogue)" on page 26. 	
2.2	HWS operation	 HWS> (for summer operation - domestic hot water only) Control: Boiler, Accumulator, HWS Heating circuits Heat circuit pumps off, mixing valve position "Closed" 	
2.3	Manual	 Manual> to test single functions of the boiler separately (Motors, pumps, etc.) Boiler control switched off HWS pump off Heating circuits: Heat circuit pumps off, mixing valve position "Closed" all automatic boiler functions are "OFF" 	
2.4	Off	 Coff> Control: Boiler OFF Frost protection function activated HWS pump off 	

- ♦ Heating circuits:
 - Heat circuit pumps off, mixing valve position "Closed"

2.5 Chimney sweep - button



Button for the chimney sweep to manually switch the boiler ON or OFF during emission tests.

If an accumulator is connected, the control automatically changes to **100% combustion**if the chimney sweep button is pressed.

All programmed control functions of the boiler are switched off by pressing this button. The boiler operates at 100% heating output, assumes very low outside temperatures and tries to transports as much as possible heat into the heating system. All regulating devices like thermostatic head valves and automatic control valves must manually be opened to ensure the appropriate heat transfer. This function ends after 2 hours automatically.

If the chimney sweep button is pressed and no accumulator is connected the control offers 2 possibilities: **Full load measurement** or **Part load measurement**.

All programmed control functions of the boiler are switched off in part load measurement. The boiler controls up to 100% combustion. After 15 min. full load - the heat output is reduced to 50%. After 5 min. a message is shown on the display "Start measuring".



Status indication of the boiler:



Because of the measured temperatures of the boiler and the flue gas temperature, the boiler control recognises the status of the boiler fully automatically.

"Boiler Off":

if no heat requirement from heat circuits or the HWS is notified, or the accumulator takes care of the demand, the boiler switches to "Off".

"Start ignition":

Fuel is being transported into the combustion chamber and the boiler monitors, ifan autonomous ignition is possible due to remaining ember.



KESSEL: Zündung

"Boiler Ignition":

The electric ignition starts and the fuel if ignited.



"Boiler combustion":

Depending on heat demand and required boiler temperature the exhaust fan (air volume) and the Lambda sensor controls the optimum fuel amount

- Combustion output range from 50 100 [%]
- "Boiler burnout":
 - Primary air to 100 %
 - Exhaust fanoutput to 100 %



"Slumber mode":

if the heat demand drops below the minimum boiler output, the status changes temporary to "Slumber mode"



V

3

V



KESSEL: Entaschung

"Boiler deash. in x Min":

if the maximum combustion time is exceeded, no more fuel is added and the boiler burns out.

"Boiler deash":

Only the ash grate performs a full rotation until it stops at original position. The turbulators clean the heat exchanger tubes.

- b the ash falls onto the ash auger and is transported and compressed in the ash box
- b afterwards the boiler returns to the required boiler status



"Boiler de-ash":

Both rotary grates are opened completely and the turbulators clean the heat exchanger tubes

b the ash falls onto the ash auger and is transported and compressed in the ash box

♦ afterwards the boiler returns to the required boiler status



"Boiler ash - suction": (optionally)

the ash suction turbine is started and the ash box is vacuumed safterwards the boiler returns to the required boiler status







Info Back end protection Pump ON / OFF

Info Back end protection

Rucklaurannebur	ng
Rücklauf-Soll	75°C
Rücklauf-Ist	61°C
Mischer	ZU
Rücklaufpumpe	EIN

Pump runs / off

Info Boiler				
Info / Boiler	Boiler status	current status of the boiler		
KESSEL: Entaschung SOLL 1ST Kesseltemp. 85% 72%C Saugzug 30% 30% Fördermenge 0% Primärluft 0% 0% O2 9.4% 0.0% 93Pa	Boiler temperature Set / Is	Water temperature in the boiler - measured with boiler sensor		
	Exhaust fan	Exhaust fan speed in % of maximum		
Glutbett 75° Einschubrost 0°	Delivery rate	the currently necessary fuel rate		
Ascherost 0° Zündung AUS	Primary air flap Set / Is	Primary air flap position in % of maximum		
	O ₂ Set/Is	Flue gas oxygen value in % - measured on the lambda sensor		
	Negative pressure	Negative pressure in Pascal - measured at the neg. press. box		
	Stoker grate	Stoker grate turn in ° of "Zero point"		
	Ash grate	As grate turn in ° of "Zero point"		
	Ignition	Ignition active / not active		
Info Accumulator				
Info / Accumulator	Filling level	Heat quantity in the accumulator in % of set accumulator temperature		
Heizkreisventil AUS Pufferladung AUS 72°C	Accumulator pump ON / OFF	Accumulator pump runs / Off		
Rücklauftemp. Soll/Ist 75°C/ 61°C	60°C	Display of the sensor temperatures on the accumulator Colour of the accumulator:		
	Return mixer OFF / OPEN / CLOSED	Return mixer stop / opens / closes		
	Return temperature Set /Is	Temperature of boiler - return		
Info External heat				
Info / External heat	Burner	Blocked, released		
Fremdwärmebetrieb AUS	External heat valve ON / OFF	External heat valve ON / OFF		
Fremdwärmeventil AUS 🔀	External heat pump ON / OFF	External heat pump ON / OFF		

Info Trend				
Info Trend	Boiler temperature	Diagram of the last 24 hours		
Kessel Boller Leistung Bolling Auf	HWS temperature			
100	Power			
80	Accumulator filling level			
60	5			
40				
20				
0 –20h –16h –12h –8h –4h				



V

Info electricity					
Info electricity Einschub 0.0A Austragung 0.0A Ascheschnecke 0.0A Einschubrost 0.0mA Ascherost 0.0mA	Stoker Agitator Ash auger Stoker grate	List of current electricity consumption			
	Info Co	unter			
Info Counter Betriebsstunden Steuerung 228h Betriebsstunden Heizung 169h Betriebsstunden Saugzug 151h Betriebsstunden Einschub 138.1h Betriebsstunden Einschub 138.1h Betriebsstunden Austragung 127.3h Betriebsstunden Aschesauger 0.5h Anzahl Entaschungen groß 7 Anzahl Ascheabsaugen 30 Laufzeit LB seit Entaschung 139 Min Entaschung frühestens nach 60 Min Entaschungen seit Entasch. groß 1 Anz. Entaschungen seit Entasch. groß 1 Anz. Entaschungen seit Aschesaugen 3 Asche absaugen bei Anz. Entaschungen seit 1	Control / Heating Ignition / Exhaust fan Stoker / Extraction Ash suction Number of de-ash cycles Number of ash suction cycles	Overview about current operation hours			
	Info serial number				
Info serial number Kessel Type Messe ECO-HK Kommissions-Nr. 1 Softwareversion V15.0b1 Seriennummer Bedieneinheit 575242 Firmwareversion 1/O Seriennummer I/O IP-Adresse 172.16.80.209 Status Kessel ID-Card 0K Systemcode 46877F28	Boiler type / Comm-No. Software version Sr-No. Control Firmware version I/O Serial number I/O IP-Address Status Boiler ID-Card	set boiler type / Commissioning number Software of control Serial number Touch display Software of boiler - control board Serial number of boiler - control board automatically or manually set IP-address OK			
Info Error					
Info Error 0305 Kessel ID-Card falsch Mi 19-03-2014 0312 Saugzuggebläse Störung Mi 19-03-2014 0344 Unterdruck zu gering Mi 19-03-2014	Error number and Description	Overview of current errors. Once the fault is rectified, the error message is no longer shown ⇒ see "List of errors" on page 36.			



V

4.1 Menu "Week clock", "Day clock"

Installer level

No. D10

No. D9 Day clock / Week clock

Dav clock	
Week clock	
HC+HWS week clock	

To set start- and stop times for heating circuits and the HWS **Day clock**

to set the same start- and stop times for each day for all heating circuits and the HWS

Week clock

to set different start- and stop times for each day for all heating circuits. The settings of the HWS remain on day clock.

HC+HWS week clock

to set different start- and stop times for each day for all heating circuits and the HWS

<Number of blocks for week clock>: maximum 7 blocks

to set different heating times for different week days.







Pos	Description	Function
1	Number of the menu displayed	for day clock 1,2,3; for week clock 1a, 1b, 1c
2	Description of the menu displayed	
3	Selection of the day Monday to Sunday	 Display of active chosen days ✤ green box
4 5	ON - times OFF - times	 Setting of heating- / reduction times for the chosen days For each day, 2 On- / Off times may be set with <+> / <-> (in 30 minutes steps) Display of active chosen time
6	<+> / <->	 change of active chosen time (in 30 minutes steps)
7		For saving active changes

Number of blocks for week clock Factory: 2 2



5 Customer settings

5.1 HWS control

Instal	ler	lev	'e

9. B1 HWS 1	<no. 2="" set<="" th=""></no.>
not available	
available	 in opera
not available available	<no. 2="" <ul="" s=""> in ope </no.>

Customer level

<no. So></no. 	1 HWS	Day c	lock	Mo-
ON	17:00	ON	:	-
OFF	20:00	OFF	:	•
No.2	HWS 1			
Set te	mperatur	е		
Factor	ry:		e	50 °C
Insta	aller lev	/el		
No. E	32 HWS	1		



 ON
 06:00
 ON
 --:-

 OFF
 22:00
 OFF
 --:-

For accumulator with internal HWS or external HWS Set the **<No. 1 HWS Day- Week clock>** and the **<No. 2 Set- temperature** "**HWS**"**>** especially for each HWS.

in operation mode

Set the <No. 1 HWS Day- Week clock>

If the HWS volume is calculated correctly, it is recommended to load the storage once a day. (in the morning or in the evening)

 For HWS loading, the HWS is loaded at the set time <No. 1 HWS Day- Week clock> to the set <No. 2 Set- temperature "HWS">

Within the **<N.0 HWS Day- Week clock>** the loading takes place, if the HWS is below the set value minus inclination.

- ♦ Example:
 - <No. 2 Set- temperature "HWS"> (60°C), <No. B2 HWS temperature switch difference> (6°C) => HWS loading starts at 54 [°C]
- Outside of the <No. 1 HWS Day- Week clock> the loading takes place:
 - If the HWS temperature is below
 - "<No. B3 HWS temperature minimum>
 - HWS loading to <No. 2 Set- temperature "HWS">
 - and within the additional release times
 - No. B90 Release all HWS temp. Minimum>
- Outside of the set times <No.1 HWS Day- Week clock> and <No. B90 release all HWS temp. Minimum> no HWS loading takes place
- 5.1.1 Monitored HWS temperatures (acc. factory settings):



V

5.2 Circulation pump for hot water

Customer level No.2a Circulation pump HWS 1 ON 06:00 ON 11:00 OFF 08:00 OFF 13:00 ON 16:00

OFF 20:00

The circulation pump pumps hot water in cycles from the HWS to the consumer, to immediately provide hot water if long distances have to overcome. Settings for the circulation pump may be performed for each HWS parametrised in the control. Release times for the circulation pump

 $\ensuremath{\,^{\ensuremath{\ensuremath{\scriptscriptstyle P}}}$ Defines the starting times of the circulation pump Parametrisation of the circulation pump

⇒ see "Parameter B - HWS:" on page 51.

5.3 Legionella programme



Installer level

No. B4 Legionella protection OFF ON No.B5 HWS 1 Legionella prot. Set temperature Factory: 71 °C No.B6 Legionella protection Weekly clock Mo Tu We Th Fr Sa Su a 17:00 b --:-c --:-- d --:-- The legionella protection programme starts if

Legionella protection - ON> especially for each activated HWS.

- The legionella protection programme heats up the HWS at the set time <No. B6 Legionella protection Weekly clock> to the set temperature <No. B5 Legionella protection Set- Temperature "HWS">.
 - Activation of the programme up to 4 times a day

	ΝΟΤΕ
	Recommended settings for the legionella protection pro- gramme
3	 Start of the protection programme within the time <no. 1="" clock="" day-="" hws="" week=""></no.>
	 Private family home: 1 x weekly Gastronomy, hotels, etcdaily activation of legionella protection

programme (subject to local regulations)



V Control

5.4 Control of heat circuits

- activated in mode <a>

 <a
- 5.4.1 Temperature control

The control of the heating circuits works with:

- "Heating" to the set room temperature
- "Reduction" to the reduced room temperature
- "Off" no room temperature control
- "Frost protection" (only pumps are on)

The control calculates the average outside temperature. Adjustment of set value settings for the room temperature (Day-reduction temperatures):

- only in small steps
 - that a thermal state of inertia of the changed temperature can be reached.
 - The changed indoor climate will be recognised the next day.

Remote control:

A slightly change of the set room temperature

<No. 4 Day room temperature> of +/- 3 [°C] can be made directly on the remote control.

⇒ see "Optional remote controls FR35 / FR40 (digital) and FR25 (analogue)" on page 26.

5.4.2 Heating

Customer level

No.3a Heat circuit 1 Week clock
Mo Tu We Th Fr Sa Su
ON 06:00 ON 15:00 OFF 09:00 OFF 22:00
Heat circuit 1
Factory: 20 °C

- Set heating times at <No. 3a Daily / Weekly clock>
 In-between are automatically times for reduction.
- Set the desired room temperature
 <No. 4 Day room temperature> between 14 26 [°C]
 <No. 5 Reduced room temperature> between 8 20 [°C]

Calculation of the flow temperature: ⇒ see "Heating curve (Steepness)" on page 25.

Graph - room temperature (acc. to factory settings)





5.4.3 Outside temperature - Shut down

Installer level

No.D12 Outside temp. down	Shu
separately	
all HC together	

Customer level

Heat circuit 1-6 & A Heating off	
Factory:	16°C
No.12 at day reduction Factory: 8°C	8°C
No.13 at night reduction Factory: -	-5°C

<No. D12 separately>- thresholds to be set separately for each heat circuit.<all HC together>- Same thresholds for all heat circuits.

3 different outside-temperature thresholds for heat circuits to be shut down @ depending on heating programme and time

- <No. 11,12,13 "Heating off"> depending on outside temperature
- <Heating off at outside temp. over>- No. 11 (16°C)
 - If the average outside temperature exceeds the set value, the heat circuit will be switched off (Summer shut down).
- <Heating off at day reduction>- No. 12 (8°C)
 - If the average outside temperature exceeds the set value at day-reduction mode, the heat circuit will be turned off.
- <Heating off at night reduction>- No. 13 (-5°C)
 - If the average outside temperature exceeds the set value at night-reduction mode, the heat circuit will be switched off.



5.4.4 Reduction

1115	
No.	D5 Switch day-reduction
mo	de
ON	06:00
OFF	22:00

5.5 HWS-priority control

Installer level

No. B60 HWS priority operation ON OFF

Reduced room temperature <No. D5 Reduced room temperature> Day reduction between 06:00 - 22:00

♦ Night reduction from 22:00 to 06:00

For a fast loading of the HWS a short switch-off of the heat circuits takes place: **<ON>**: (Priority control)

- Heat circuits with **Pumps**:
 - Switch off of heat circuit pumps
 - during the complete HWS loading
 - ♦ immediate HWS loading
 - no heat transfer from the boiler to the heat circuits
- Heat circuits with **mixer**:
 - Reduction of the heat circuits during HWS loading
 - during the complete HWS loading
 - $\$ immediate HWS loading
 - rightarrow reduced heat transfer from the boiler to the heat circuits
- ♦ Calculation of the flow temperature reduction:

Example: Boiler SET: 60; Boiler IS: 45; Reduction factor 1.0; => Reduction heat circuit flow temperature for: (60-45)*1.0)= 15 °C

<OFF>: No switch off of the heat circuit pumps during HWS loading







V Control

5.6 Frost protection

Installer level

No. D2 frost protect	ion
Pump on if outs. temp. I	below
Factory: 1 °C	1°C
No. D3 frost protect	ion
Flow-Set temperature	
Factory: 7°C	7°C

Two safety steps to activate the frost protection function

- Outside temperature below parameter <No. D2 Frost prot. > (1°C)
- Start up of heat circuit pumps, Mixers remain "**Closed**"
- Boiler- or flow temperature below parameter <No. D3 Frost protection> (7°C)

Start up of the boiler and mixing valve control activated

5.7 Accumulator control

⇒ see "Parameter C - Accumulator" on page 52.

5.8 Blockage protection

To prevent any blockage of pumps or mixing valves after a long period of standstill, the devices starts automatically.

- Every Monday at 12:00 a.m.
- Start heat circuit pumps (1 Minute)
- Mixing valves open and close once

5.9 Heating curve (Steepness)



• Adjustment of the steepness of the heating curve **<No. A2 Heat circuit 1>** Prerequisite for a stable room temperature at varying outside conditions:

- accurate adjustment of the heating curve
- correct dimensioning of the boiler accoring to heat demand calculation.



The heating curve defines the flow temperature according to the average outside temperature.

☞ Selectable for each heat circuit (1-6).

The displayed curve is for a room temperature 20 °C [©] For any other desired room temperature:

move curve parallel (upwards / downwards) **Example:**

Heat circuit with: Steepness: 1.5; Day-room temp.: 20 °C Boiler in heating mode; Outside temperature: 0 °C => Flow temperature: 50 °C

Change heating curve only in small steps, so a thermal state of inertia of the changed temperature can be reached. The changed indoor climate will be recognised the next day.



6 Optional remote controls FR35 / FR40 (digital) and FR25 (analogue)

One heat circuit may be parametrised per remote control.

- one heat circuit or extension control board (HKA digital remote controls only)
- 2 heat circuits per extension module (HKM 0 2)
- 2 heat circuits per heat circuit controller (HKR 1 8)

6.1 Digital remote control FR35

The remote control may be parametrised with or without room temperature sensor. FR35 is also available in radio version.

⇒ Please see installation manual of remote control

Only in operation mode <Automatic>

Selection of operation modes of the boiler

• Selection of modes at remote control

Operation modes:

<u>OFF</u>

The heat circuit is switched off (except frost protection mode)



Automatic

O Boiler operates on regular Day / Week mode

CONTINUOUS - REDUCTION

Boiler switches to permanent reduction mode

CONTINUOUS - HEATING

Boiler switches to permanent heating mode

PARTY

Boiler switches to heating mode and changes automatically to AUTO at next set heating time

REDUCTION

Boiler switches to reduction mode and changes automatically to AUTO at next set heating time

Fine adjustment of room temperature:



: Increase / Decrease for +/- 3 °C

Fault lamp:

Lights up if error occurs

Display - Parameters:

Select which temperature should be shown on the remote control (FR35)

- HWS temperatures 1 3 and A
- Accumulator filling level







V Control

6.2 Digital remote control FR40

With the FR40, the room temperature may easily be changed and also heating or reduction settings may be adjusted. All heating temperatures and times may be adjusted with the FR40. All functions of the boiler control may be changed with the FR 40 from the remote control position.

⇒ Please see installation manual of remote control

Operation modes: OFF

The heat circuit is switched off (except frost protection mode)

AUTOMATIC

Boiler operates on regular Day / Week mode

CONTINUOUS - REDUCTION

Boiler switches to permanent reduction mode

CONTINUOUS - HEATING

Boiler switches to permanent heating mode

PARTY

Boiler switches to heating mode and changes automatically to AUTO at next set heating time

REDUCTION

Boiler switches to reduction mode and changes automatically to AUTO at next set heating time



Fine adjustment of room temperature:

+: Increase up to 3 [°C]

-: Reduction up to 3 [°C]

6.3 Analogue remote control FR25 (only at HKM- or HKR heat circuits)

The remote control may be installed with or without room sensor.

⇒ Please see installation manual of remote control

Only in operation mode **<Automatic>** Q^{Auto} **Rocker switch:**



Boiler switches to permanent reduction mode Boiler operates on regular Day / Week mode

Boiler switches to permanent heating mode

Rotary knob:

Fine adjustment of room temperature:



+: Increase up to 3 [°C]

-: Reduction up to 3 [°C]

Fault lamp:

Lights up if error occurs





VI

Chapter VI: Commissioning

	CAUTION	
	Moving parts in the area of the fuel extraction system, ash extraction system and combustion grate.	
	Risk of crushing!	
	 Make sure that no persons stay in any danger zone. Do not grasp in any reachable mechanical parts. Do not stand on the boiler system. Make sure that no foreign parts (tools, etc) remain within any boiler component. 	
	DANGER	
	Switch on through trained and authorised personnel Risks through unpredicta- ble operating conditions!	
	 Switch on / First start up shall be carried out through Hargassner GmbH or spe- cially trained staff ! 	
1 Checks prior commissioning		
	☑ safety on-site and plumbing and electrical installations	
	⇒ Siehe Montageanleitung "Einrichtungen bauseits"	
	☑ Boiler assembly	
	Check all necessary components	
to correct assembly, correct function, correct rotation of all motors,		

2 Start of commissioning

After professional installation and inspection of all necessary safety requirements the commissioning can be performed according to the enclosed commissioning check list.



ATTENTION

The **Commissioning** must be executed through a technician with Hargassner commissioning certificate. The completed commissioning check list must be sent back within 30 days after commissioning, including the commissioning identification number to , **otherwise the warranty is voided**. A copy remains in the commissioning book on-site.

2.1 Customer instructions

- ☑ Explain "Cleaning- and maintenance intervals"
 ⇒ see "Cleaning intervals" on page 32.
- ☑ Explain "Inspections prior any fuel refill"
 ⇒ see "Inspections prior starting up the boiler" on page 30.
- \checkmark See "inspections prior starting up the boller" of page \blacksquare Explain "How to operate and troubleshooting"
 - \Rightarrow see "Rectify and clear errors" on page 35.



Chapter VII: Operation

1 Safety instructions

DANGER



Missing, defective or bridged safety devices and boiler parts!

Death, injuries, damages caused by not correctly operating or missing safety devices or plant parts.

- Check safety devices and boiler components carefully for proper and intended function.
- Safety devices should not be modified or bypassed.
- In case of malfunction or defect, perform immediate repair measures.
- Place, position and function of all safety devices must be known.

1.1 Measures in case of danger

- 1.1.1 Fire in the boiler room
 - □ Switch-off main switch prior any fire-fighting operations
 - ♥ Disconnect main power supply
 - The switch-off the boiler and unplug the unit from the mains

1.1.2 After power loss

Do not open the boiler door or touch any parts of the boiler at/after power loss

- Danger of deflagration
- Danger of crushing through augers

After the electrical supply is switched on again, the control starts in **"Heat up"** mode and monitors the flue gas temperature.

- Series Series
 - The boiler is in combustion mode and the control controls the heat transfer according to set parameters
- 1.1.3 Leak in heating water system (no water)

If insufficient water pressure occurs, there is also insufficient heat transfer from the boiler to the heat circuits, HWS and accumulator.

- ♦ Danger of boiler overheating
- Do not continue to heat up the boiler.
- Fix leakiness
- □ fill / refill water system
- Check water pressure
- 1.1.4 Check boiler for leakages (Smoke)
 - Do not continue to heat up the boiler
 - Check sealings of doors and maintenance openings and renew
- 1.1.5 Auger blockage
- Do not touch the augers
 - Danger of crushing at sudden release of blockages
- Press<Reverse> Button of the blocked auger max. 2 seconds
- □ Remove blockages and clean augers with tools only.
 - Switch-off and lock<Main switch>

VII



VII

2 Start-up boiler for the first time

After finished commissioning the boiler may be started the first time. Please proceed as follows.

- for first fill, only use a small amount of fuel, distribute it under the spring blades
 - Install a "sloping floor" with fuel
- switch to operation mode "AUTO" or "HWS"
 Boiler starts automatically if hot water is needed

3 Settings recirculation (optionally)



- □ For clinker-causing agro-fuels like
 - Corn cobs or miscanthus, the recirculation damper is pulled out completely. Press in the damper in 5mm steps daily, check the ash every day. If clinker still occurs - pull out the damper again (for 5mm)
- If wood chips or wood pellets are used, the damper is pushed in completely. If clinker appears for any reason also with wood chips or wood pellets, proceed as previously described.

4 Inspections prior starting up the boiler

- ☑ Check water pressure in the boiler-, heat-, HWS- and accumulator circuit.
- ☑ Monitor touch display for news (Errors, boiler status).
- ☑ Rectify errors
- ☑ Check and lock fuel storage room



Kapitel VIII: Cleaning, Maintenance

D A N G E R			
 Rotating augers and moving parts ! Amputation, crushing of hands through touching moving parts or augers. Omit access to augers or motors at operating boiler. Fix ash box correctly on the boiler and lock. Do not perform any works on the plant, if any other person is in the danger zone. Remove blockages and clean augers with tools only. 			
CAUTION			
 Moving parts in the fuel extraction system, hollow space formation in the fuel storage room Unpredictable operation conditions The spring blades of the agitator system are retracted under the cover disc if the storage room is filled completely. These springs may shoot up suddenly. Remove fuel bridges with rods or shovels only Wear safety shoes Observe fuel storage room sticker! 			
DANGER			
 <u>Disconnect main power supply</u> Touching open or free terminals, cables and equipment components can lead to severe injury or death! Disconnect power supply prior any cleaning or maintenance works. Switch-off and lock<main switch=""></main> 			
D A N G E R			
After <main off="" switch=""> or <off> - mode: Risk of injury due to grasping into a danger zone - Re-commissioning! Crushing, amputation. • After actuation of the <main off="" switch=""> or <off> switch, do not grasp into any danger zone.</off></main></off></main>			

VIII

1 Cleaning intervals

D A N G E R		
Risk of fire and explosion		
 Risk of burning through inflammable materials. Do not spray any inflammable sprays on hot surfaces. (e.g: Lubricate moving parts in the combustion chamber Spray drops can cause explosive fire. Do not use any inflammable lubricants Let boiler (combustion area) cool down. 		
Risk of fire in the vacuum cleanerLet ash cool down prior vacuum-cleaning		
ΑΤΤΕΝΤΙΟΝ		
 Check sealings Formation of dust and smoke due to boiler leakages Clean sealing surfaces with industrial alcohol and a dry and soft (scratch-free) cloth only. Make sure the cleansing material is evaporated before commissioning! 		
ΑΤΤΕΝΤΙΟΝ		
 Empty ash box on regular intervals! Dirt and breakdown through ash escape. Depending on maintenance interval, empty and clean the ash box. If the ash box is overfilled, ash may escape from the box. Ash box must be positioned correctly and locked on both sides. 		

- $\hfill\square$ For best performance of the boiler it is necessary to clean the boiler extensively.
 - or after an error or several operating hours
 - at least once a year
- Cleaning intervals change or shorten depending on level of fuel quality

Depending on country regulation and nominal heating output of the boiler, a professional maintenance through the manufacturer of the boiler must be carried out in regular intervals. (Every 1-3 year(s)) The maintenance has to be carried out through Hargassner trained and authorised personnel.

Hargassner Maintenance contract

1.1 Maintenance contract

If you sign a maintenance contract with Hargassner, the cleaning and maintenance takes place during the annually carried out service through Hargassner authorised personnel.

VIII Cleaning, Maintenance

1.2 Weekly/monthly cleaning and maintenance

1.2.1 Weekly intervals

- once a week, check the boiler and fuel storage visually.
 - $\$ rectify identified defects immediately
- Empty ash box (1) if required
- At regular operation small cracking may occur in the refractory. These cracks are stress crackings, and an expansion joint is built. This process (stress crackings) is normal and does not cause any problems or affect the function of the boiler. As a result, there is no right to claim under guarantee.

1.2.2 Monthly intervals

⇒ See maintenance book "Monthly checks"

- Check all safety devices (2).
 - (acc.to Austrian law and fire authorities TRVB H118)
 - this may be waived if an annual inspection through the manufacturer is made (Siehe "Maintenance contract")
- Check of the flue pipe (3)
- $\ensuremath{\square}$ appropriate condition of the boiler room
- Readiness of portable fire extinguishers
- appropriate storage of ash
- Remove debris (4) under the agitator
 - @ after each emptying of the storage room



Pos.	Tasks of maintenance	Intensity m = monthly
1	☑ Clean and empty ash box (<i>optionally ash suction)</i>	as required
2	☑ Safety devices (Main switch, RSE, ETÜ, HLE / SLE, TÜB)	1x m (waives at maintenance contract)
3	☑ Check and clean flue pipe (more often at excessive contamination)	1x m
4	☑ Remove debris and larger wood pieces	after each storage room emptying



1.3 Annual cleaning* / after an error (Operation hours)





Pos.	Tasks of maintenance	Pos.	Tasks of maintenance
1	Pull out turbulators, tap off and clean the turbu- lator space	8	Grease the agitator grease nipple
2	Vacuum exhaust fan and flue pipe	9	Grease rivet at position switch
3	Clean rust holes	10	Disconnect, remove and clean the lambda sensor
4	Clean combustion chamber with ash cleaner	11	Check sealings
5	Remove and clean flame concentration plate	12	Remove ash under the grate (especially at ash grate)
6	Remove maintenance opening and clean fly ash space	13	Vacuum recirculation
7	Clean ignition	14	Check safety devices (Main switch, ETÜ, HLE, SLE, TÜB, warning devices)

* The cleaning has to be performed depending on operation hours and fuel-quality.

1.3.1 Cleaning of Lambda sensor

- Disconnect sensor and unscrew
 - $\hfill\square$ Place sensor head down
 - $\ensuremath{\square}$ and remove dirt with a soft cloth

Debris falls down

ΝΟΤΕ
 Do NOT "tap" the sensor! Do not blow with compressed air Do not touch the sensor with sharp items and do not use any chemicals for cleaning (Brake cleaning fluid, etc)



Chapter IX: Troubleshooting

	ATTENTION
	Changes compared to regular operation
	 due to higher heating output, higher temperatures or vibrations of motors, unusual noises or smells, release of safety devices, etc. Immediately call the installer / Hargassner Perform mandatory maintenance and inspection tasks regularly.

1 Errors

USSENTEM

BOILER

HK1: AUS Error messages to be read on the touch display.

on the Standard-Display a warning triangle appears at the position where the error occurs (A)
 The following instructions to rectify errors are aimed for the direct user of

The following instructions to rectify errors are aimed for the direct user of this boiler.

If it is not possible to rectify the error through the operator, the installer / Hargassner must be informed.



1.1 Rectify and clear errors

After rectification of the error:



1.2 Retrieve error list

If error messages occur:

- □ Press <ERROR> (B) button
 - ♥ Display of error list (latest errors)





2 List of errors

No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)
No display	Green lights H7 board do not light	Fuse F13 defective, or L1 missing, or connection from control board to the operating unit defective or missing	Replace fuse F13 (see board sticker); Check power supply L1, or cable from control board to operating unit;
1	Attention Over temperature - STB triggered"	Over temperature on the boiler or STB- supply defective or overheated at manual heating, air in the heating system or pump(s) defective	Cool down boiler, remove protective cap and press the button on the STB (boiler front); Let STB - supply be checked by an electrician; check pumps, call service department and change the control board;
2	Over current stoker auger	Gagger in auger channel or rotary valve, knife of rotary valve defective or blockage in the auger	Remove debris, use parameter No. 4 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; call service department
3	Over current fuel extraction auger	Gagger in the extraction channel or auger blockage	Remove debris, use parameter No. 3 in "Manual" mode (No. 3a for RA-2) and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; call service department
5	Over current connection auger	Gagger in the extraction channel or auger blockage	Remove debris, use parameter No. 5 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; call service department
6	Thermal protection stoker auger	Overload of motor through debris or electronic motor protection set incor- rectly	Remove debris, use parameter No. 4 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; check rotary valve for stiffness; call electrician or service department and change control board;
7	Thermal protection extraction auger	Overload of motor through debris or electronic motor protection set incor- rectly	Remove debris, use parameter No. 3 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; call electrician or service department and change control board;
8	Thermal protection ash auger	Overload of motor through debris or electronic motor protection set incor- rectly	Remove debris, use parameter No. 2 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; this error may also be a result of a stiff heat exchanger cleaning system or a sluggish fly ash extraction; call electrician or service department and change control board;
9	Thermal protection connection auger	Overload of motor through debris or electronic motor protection set incor- rectly	Remove debris, use parameter No. 5 in "Manual" mode and drive auger forward or backward, (Check motor current on display); replace eventually worn out auger parts; check electronic motor protection; call electrician or service department and change control board;
10	Flue gas sensor connected incor- rectly	Sensor connected incorrectly (only at commissioning) or control board defective	Have connection polarity checked by an electrician, otherwise replace the sensor or the left board;
11	Interruption flue gas sensor	Sensor not connected or connection interrupted	Connect sensor; check cable and contacts; replace sensor or board;
12	Boiler sensor short circuit	Short circuit in the sensor or in supply line	Let cables or sensor check by an electrician.
13	Interruption boiler sensor	Sensor not connected or connection interrupted	Connect sensor; check cable and contacts; replace the defective sensor with another sensor, if there's a different error, replace the sensor. If the same error is shown, replace the control board.



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)
14	Short circuit HWS 1 sensor	Short circuit in the sensor or in supply line	
15	Interruption HWS 1 sensor	Sensor not connected or connection interrupted	
16	Outside sensor short circuit	Short circuit in the sensor or in supply line	Connect sensor; check terminal points and plugs and check
17	Interruption outside temperature sensor	Sensor not connected or connection interrupted	check by an electrician;
18	Short circuit flow sensor HC1	Short circuit in the sensor or in supply line	Hint: Exchange the alleged sensor plug with another plug, if another error occurs the sensor is defective and must be
19	Interruption flow sensor HC1	Sensor not connected or connection interrupted	has to be changed; call service department;
20	Short circuit flow sensor HC2	Short circuit in the sensor or in supply line	
21	Interruption flow sensor HC2	Sensor not connected or connection interrupted	
22	Short circuit remote control sensor HC1	Short circuit in the sensor or in supply line of FR25	for short circuit: Check clamp points; the resistance value of the remote control must be in position "Auto" between 3340
23	Interruption remote control sensor HC1	FR25 sensor not connected or connection interrupted	Ohm and 3626 Ohm (Room temperature between 5°C and 25°C); for interruption: Connect the remote control, check connec-
24	Short circuit remote control sensor HC2	Short circuit in the sensor or in supply line of FR25	tions and clamping points as well as the corresponding param- eters No. A6 (or A16, A26, A36, A46, A56, A66) in the installer
25	Interruption remote control sensor HC2	FR25 sensor not connected or connection interrupted	level settings; otherwise replace the remote control or the extension module HKM0 and contact service deparment;
26	Ignition time over-run	the flue gas temp. did not rise for the set value (P41) within the ignition attempt time (P1), or the O2 did not drop within the time (P1) and the duration (P43) under the value (P42); no or too wet material; too much ash/ clinker in the combustion chamber; flue gas sensor not in the flue pipe; ignition defective	Check installation of the flue gas sensor and clamp points; check fuel; if the negative pressure value is not reached, check all sealings at all maintenance openings, also check correct function of the exhaust fan; Check ignition in manual mode (No. 11); clean ignition tube; Check ash extraction in manual mode (No.2); check fuel level sensor (at cold boiler condition, manually lift for 90°C and compare with "Info Boiler"; let cables, clamps and plug check by an electrician;
27	Flue gas temperature under-run	During combustion the flue gas temperature drops under the set value (K14) for the set duration of (K15)	Check installation of flue gas sensor; too wet fuel; too much ash or clinker in the combustion chamber; check proper function of the agitator, stoker auger and de-ash in manual mode (No.3, No.4, No.5), clean combustion chamber;
28	Allowed O2-stop time over-run	Contact error of the lambda sensor or lambda sensor defective	Lambda sensor very intensely dirtied (clean), then perform a function check in manual mode No. 13; let check terminal points and plugs by an electrician; replace the lambda sensor; the boiler system can run without lambda sensor with reduced heating output until replacement; disconnect lambda sensor and confirm;
30	Low battery. Please exchange!	Batteries powering date/time memory are close to being empty	Exchange battery of the control unit
34	Accumulator sensor top - short circuit	Short circuit in the sensor or in supply line	
35	Interruption accumulator sensor top position	Interruption in the sensor or in supply line	
36	Accumulator sensor bottom - short circuit	Short circuit in the sensor or in supply line	see No. 0014 to No. 0021;
37	Interruption accumulator sensor bottom position	Interruption in the sensor or in supply line	Position and parametrisation of sensors on the boiler or at HKM 0-2 possible;
38	Accumulator sensor mid - short circuit	Short circuit in the sensor or in supply line	
39	Interruption accumulator sensor mid position	Interruption in the sensor or in supply line	



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)	
45	Back end protection temperature not reached	Back end protection pump set incor- rectly or mixer defective. The first two times a warning occurs, the third time the boiler switches off. Error must be rectified	Check correct return sensor position; set pump correctly; Exchange pump or use bigger pump; check return mixer function (when available); call installer; ATTENTION: affects boiler life time!	
46	Return sensor - short circuit	Short circuit in the sensor or in supply line		
47	Interruption return sensor	Interruption sensor or in cable or sensor not available	see No. 0014 to No. 0021.	
52	Short circuit external sensor	Short circuit in the sensor or in supply line	See NO. 0014 10 NO. 0021,	
53	Interruption external sensor	Interruption in the sensor or in supply line		
62	GSM module not connected	No connection between GSM-module and control	Check data cable; LED on the GSM-module; On-/Off switch on GSM-module (should not be set to OFF); replace GSM-module;	
65	GSM module transmission error	GSM-module was not able to send SMS due to insufficient credit on the SIM-card or no connection to the net provider.	Check credit amount on SIM-card and charge if necessary o activate SIM-card; Check GSM-signal with mobile phone from the same provider and eventually re-position or extend antenna;	
67	Parameter error. Load factory settings.	Internal error in the parameter memory	Check parameters and make adjustments where necessary; change the boiler control unit if the error persist despite the changes;	
90	Boiler IO not connected	Bus-cable-connection or board defective	Change bus-cable-connections, control unit, boiler control board; call service department;	
91	Max. control board temperature exceeded.	too high temperature at control board location, control board is dirty or does not cool down	Temporary, slightly open control box covers, to cool down th board; blow the dust from the board, call service department	
100	Extension module HKM 1 not connected	no connection (CAN1 - blue bus) to extension module 1	Set the extension module's address switch to "1"; check HC's connection and bus wiring; replace extension module 1;	
103	Short circuit HWS 2 sensor	Short circuit in the sensor or in supply line		
104	Interruption HWS 2 sensor	Interruption in the sensor or in supply line		
107	Short circuit flow sensor HC3	Short circuit in the sensor or in supply line	see No.0014 to No.0021	
108	Interruption flow sensor HC3	Interruption in the sensor or in supply line	on extension module HKM 1	
109	Short circuit flow sensor HC4	Short circuit in the sensor or in supply line		
110	Interruption flow sensor HC4	Interruption in the sensor or in supply line		
111	Short circuit remote control sensor HC3	Short circuit in the remote control FR25 or in supply line		
112	Interruption remote control sensor HC3	Short circuit in the remote control FR25 or in supply line	see No.0022 - No.0025	
113	Short circuit remote control sensor HC4	Short circuit in the remote control FR25 or in supply line	on extension module HKM 1	
114	Interruption remote control sensor HC4	Short circuit in the remote control FR25 or in supply line		
120	Extension module HKM 2 not	no connection (CAN1 - blue bus) to	Set the extension module's address switch to "2"; check HKM's connection and bus wiring: replace extension module 2:	



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)
125	Short circuit HWS 3 sensor	Short circuit in sensor or in supply line	
126	Interruption HWS 3 sensor	Interruption in sensor or in supply line	1
127	Short circuit flow sensor HC5	Short circuit in sensor or in supply line	see No.0014 to No.0021
128	Interruption flow sensor HC5	Interruption in sensor or in supply line	on extension module HKM 2
129	Short circuit flow sensor HC6	Short circuit in sensor or in supply line	1
130	Interruption flow sensor HC6	Interruption in sensor or in supply line	1
131	Short circuit remote control sensor HC5	Short circuit in the remote control FR25 or in supply line	
132	Interruption remote control sensor HC5	Short circuit in the remote control FR25 or in supply line	see No.0022 - No.0025
133	Short circuit remote control sensor HC6	Short circuit in the remote control FR25 or in supply line	on extension module HKM 2
134	Interruption remote control sensor HC6	Short circuit in the remote control FR25 or in supply line	
135	Heat circuit control board A (HCA) not connected	no connection (CAN1 - blue bus) to heat circuit control board HCA (installed on boiler or at HKM 0-2)	Set the extension module's address switch to "A"; check HC's board connection and bus wiring; replace extension module A;
136	Short circuit flow sensor HCA	Short circuit in sensor or in supply line	
137	Interruption flow sensor HCA	Interruption in sensor or in supply line	see No 0014 to No 0021
138	Short circuit HWS A sensor	Short circuit in the sensor or in supply	See 10.0014 to 100.0021
120		line	Heat circuit board A
139		line	
140	Extension module HKM U not connected	no connection (CAN1 - blue bus) to extension module 0	Set the extension module's address switch to "U"; check HKINIS connection and bus wiring; replace extension module 0;
150	No connection to heat circuit controller HKR 1	Bus-Communication CAN2 (red Bus) to HKR interrupted, Bus cable	Check HKR display (fuses); LED flashes at BUS-Communi- cation; check terminating resistors;
151	No connection to heat circuit controller HKR 2	supply missing at HKR; boiler control board or control defective; internal	(ca. 2 V between L and Minus (-), or. H and Minus (-))
152	No connection to heat circuit controller HKR 3	BUS-cable defective; terminating resistors set incorrectly	cable, check boiler control board (Voltage 2V), replace control or HKR;
153	No connection to heat circuit controller HKR 4		Check HKR-address (only at commissioning); see user manual HKR;
154	No connection to heat circuit controller HKR 5		
155	No connection to heat circuit controller HKR 6		
156	No connection to heat circuit controller HKR 7		
157	No connection to heat circuit controller HKR 8		
210	Remote FR35 not connected (HKA -	no connection to digital remote control	Check parameter A6 (or A16, A26, A36, A46, A56, A66); check
216	HC6)	FR35	bus wiring; replace digital remote control;
220	Remote FR40 not connected (HKA -	no connection to digital remote control	Check parameter A6 (or A16, A26, A36, A46, A56, A66); check
226	HC6)	FR40	bus wiring; replace digital remote control; see user manual FR40;
230	Communication error to leading boiler (only at cascade control)	no connection to the leading boiler (Boiler A)	Check parameter F1: must be set to "Cascade available" at each other boiler; Check parameter F2: each boiler has to have a unique IP-address (no duplicated addresses); Check BUS-wiring; check internal BUS cable between control unit and control board;
231	Slave boiler failed (only at cascade control)	no connection to one of the slave boilers (Boiler B-F)	Check parameter F6: correct number of slave boilers set; see No. 0230
232	Error slave boiler (only at cascade control)	An error has occurred on the following slave boiler	This message will only be shown on the leading boiler (Boiler A). The leading boiler and the other slave boilers continue as normal. Confirm message on the leading boiler and rectify the error on the slave boiler.



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)	
240 - 246	Connected remote control does not match with parametrisation (HKA - HC6)	Remote control parametrisation does not match with parametrisation heat circuit remote control	Check parametrisation of the remote control and the heat circuits; see user manual of the according remote control;	
305	Boiler-ID-card wrong	Boiler-ID wrong	Change Boiler-ID, Boiler trial for 30 days with incorrect Boile ID	
306	Boiler-ID-card missing	Boiler-ID or connection defective	Change Boiler-ID, Boiler trial for 30 days with incorrect Boiler-ID	
309	Ash box full! (Warning)	Ash box full or stiffness of the ash auger	Empty ash box; Heating to be continued; Control tries to drive the ash auger every 5 minutes; if this does not work => Error 314	
310	Did not reach initiator cleaning rod and de-ash final position	Cleaning rod and ash extraction do not return to original position after cleaning	Check cleaning rod and fly ash damper that they are easy running (Manual mode No.2, the initiator function is shown),	
311	Did not reach initiator cleaning rod and deash stroke level		check rubber pads and rod; Check correct function of initiator (behind the cover, next to the control board); (Heating operation to be temporary continued)	
312	Error exhaust fan	The required exhaust fan speed has not been reached	Test exhaust fan in manual mode (No.1); check if green and black plug are connected correctly on the fan; Clean casing and fan impeller, the motor must be smooth running; let check plugs and clamp ports through an electrician; replace the motor;	
313	Incorrect position of ash box	The ash box or the cover is not placed correctly and close enough to the safety switch.	Fix ash box tight on boiler; ash box cover must be closed; let safety switch, cables, clamp points and plugs check by an electrician; (heating operation to be continued, de-ash and ash suction is blocked)	
314	Ash box full!	Ash box full or stiffness of the ash auger	Empty ash box, check ash auger for smooth operation (Manual mode No.2); disassemble ash ejector flange, pull blockage rod (behind the cover, below the stoker) and pull out ash auger in front; overfill in the ash room below the grates or fly ash overfill or debris in the ash auger; remove blockages; call service department:	
315	Position switch RA-lid partly opened (Warning)	Lid of the extraction auger not completely closed, cable defective or material jam in the RA	Heating operation to be continued; Control tries 4 times to empty the auger; if not possible Error 366	
316	Position switch RA-lid open	Lid of the extraction auger open or switch not connected	Stop screw has been removed and lid is opened; Safety switch connected? (Switch position displayed on the Info window); safety switch, cables, clamp points and plugs to be checked by an electrician;	
317	Position switch of connection auger RA-lid partly opened (Warning)	Lid of the connection extraction auger not completely closed, cable defective or material jam in the connection auger	Heating operation to be continued; Control tries 4 times to empty the auger; if not possible Error 368	
318	Position switch Connection - RA-lid open	Lid of the connection extraction auger open or switch not connected	Stop screw has been removed and lid is opened:	
319	Position switch RA-lid 1 open	Lid of the extraction auger 1 open or switch not connected	Safety switch connected? (Switch position displayed on the Info window); safety switch, cables, clamp points and plugs to	
320	Position switch RA-lid 2 open	Lid of the extraction auger 2 open or switch not connected	be checked by an electrician;	
321	Stoker grate - position not reached	The stoker grate can not reach the set position (0° position)	Empty stoker grate in manual position (No.6); remove debris from the grate ash room; check grate motor; check position sensor and magnetic transmitter; (Heating operation to be temporary continued at defective grate, unplug the grate motor, set grate manually into horizontal position and confirm error)	
322	Ash grate - position not reached	The ash grate can not reach the set position (0° position)	Empty ash grate in manual position (No.7); remove debris from the grate ash room; check grate motor; check position sensor and magnetic transmitter; (Heating operation to be temporary continued at defective grate, unplug grate motor, set grate manually into horizontal position and confirm error)	
323	Stoker-grate sensor invalid signal	Position sensor stoker grate is not connected or defective	Cables, clamp points and plugs to be checked by an electrician, replace sensor;	



IX

Troubleshooting

No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)	
324	Ash-grate sensor invalid signal	Position sensor ash grate is not connected or defective	Cables, clamp points and plugs to be checked by an electrician, replace sensor;	
325	Primary air flap defective	The primary air flap can not reach the set position or does not move	Test primary air flap in manual mode (No.12); Through pressing the release, the primary air flap can be moved manually and may be checked to smooth operation. (behind the covers, below the stoker); (Heating operation may be temporary continued at defective primary flap, therefore set manually to 30%); cables, clamp points and plugs to be checked by an electrician; replace flap motor	
326	Primary air flap not connected	Primary air flap is not connected or defective	(Heating operation may be temporary continued at defective primary flap, therefore set manually to 30%); cables, clamp points and plugs to be checked by an electrician; replace flap motor	
327	Fuel level sensor invalid signal	Position sensor ash grate is not connected or defective	(Heating operation may be temporary continued at defective sensor, therefore disconnect sensor and enter); cables, clamp points and plugs to be checked by an electrician; replace sensor;	
328	Emergency stop has been operated	Emergency stop operated or plug with bridge removed	Unlock emergency stop or re-insert plug with bridge Clamp (64 / 65)	
329	Negative pressure sensor defective	Negative pressure box is not connected or defective	(Heating operation may be temporary continued at defective sensor (with reduced heating output), therefore disconnect sensor and enter); cables, clamp points and plugs to be checked by an electrician; replace sensor;	
330	Safety bridge relays defective	Board defective	Replace board and call service department.	
331	Safety switch storage room open	Emergency stop operated or plug with bridge removed	Unlock emergency stop or re-insert plug with bridge	
335	Temperature in fuel storage room 2 exceeded	Temperature in fuel storage room 2 exceeded	If the warning device in the fuel storage room (TÜB) triggers, immediately initiate further measures (call fire department); if	
336	Temperature in fuel storage room exceeded	Temperature in fuel storage room exceeded	the error is due to a defective control board, the heating operation may be temporary continued with without the TÜB sensor; (Set parameter D21 to "not available" => DANGER: no warning at exceeded fuel storage room temperature!)	
337	Temperature in the stoker auger exceeded	The temperature on the stoker auger is high, because the flue connection is minimised or a burn back occured	Check boiler, flue pipe and exhaust fan for dust or ash and clean; if burn back, check the tightness of the rotary valve; remove the tube from the negative pressure box and blow in direction of the boiler.	
338	Interruption TÜB 2 sensor			
339	Short circuit TÜB 2 sensor		see No.0014 to No.0021	
340	Interruption TÜB sensor	Interruption or short circuit in the	the heating operation may be temporary continued without	
341	Short circuit TÜB sensor	sensor or in supply line	TUB; (Set parameter D21 to "not available" -> DANGER: no	
342	Interruption ETÜ sensor		warning at exceeded fuel storage room temperature!)	
343	Short circuit ETÜ sensor			
344	Negative pressure too low	The speed-controlled exhaust fan does not reach the desired negative pressure in the boiler	all boiler openings must be closed (Maintenance openings, combustion door); check neg. pressure box, exhaust fan and flue pipe; blow through neg. pressure tube in direction of the boiler; Check clamp points, cables and plugs;	
349	Lambda sensor not connected or defective	Contact error of the lambda sensor or lambda sensor defective	Lambda sensor very intensely dirtied (clean), then perform a function check in manual mode No. 13; let check terminal points and plugs by an electrician; replace the lambda sensor; the boiler system can run without lambda sensor with reduced heating output until replacement; disconnect lambda sensor and confirm;	



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)	
350	!Ash suction de-activated! Ash bin full or sensor disconnected.	The sensor in the ash bin reports "Full" or not connected	Empty ash box; clean sensor; if no sensor is available set parameter D6a to "without sensor"; cables, clamp points and plugs to be checked by an electrician;	
351	Ash suction emergency shut down	for manual shut down during ash suction	Message disappear after ash suction process has finished	
352	Delivery rate too low! Check fuel	The fuel delivery rate is too low	Fuel storage low, refill; Check spring blades on agitator; bridging of fuel; wrong fuel set (parameter 19)	
353	Fuel storage empty or firebed sensor pinned	Fuel storage is empty or the firebed sensor does not move any more	Fuel storage is empty, refill: Check agitator system and stoker auger in manual mode (No.3 and No.4); check fuel level sensor's ease of movement; remove debris; check correct installation of sensor, magnet and connection shaft of tongue;	
354	Calibrate firebed sensor	Wrong boiler type (L/R) set or sensor defective;	Check parameter Z1a; Calibrate Firebed sensor (GBF) new; replace sensor;	
360	Over current agitator auger 1	Bulky part in the auger channel	see No. 003	
361	Over current agitator auger 2			
362	Thermal protection agitator auger 1	Overload of motor through debris or		
363	Thermal protection agitator auger 2	rectly	see No. 007	
364	Position switch RA1 - cover lid open (warning)	Lid of the extraction auger 1 not completely closed, cable defective or material jam in the RA-1	Heating operation to be continued; Control tries 4 times to empty the auger; if not possible Error 367	
365	Position switch RA2 - cover lid open (warning)	Lid of the extraction auger 2 not completely closed, cable defective or material jam in the RA-2	Heating operation to be continued; Control tries 4 times to empty the auger; if not possible Error 368	
366	Material jam RA-lid	Lid of the extraction auger not completely closed, cable defective or material jam in the RA		
367	Material jam RA 1 - lid	Lid of the extraction auger 1 not completely closed, cable defective or material jam in the RA-1	Fuel jam, remove debris; lid of extraction auger must be completely closed; safety switch, cables, clamp points and plug to be checked by an electrician;	
368	Material jam RA 2 - lid	Lid of the extraction auger 2 not completely closed, cable defective or material jam in the RA-2		
410	no fuel in RA-1 Currently extraction from RA-2	Fuel empty at RA-1	Refill fuel at RA-1; Control switches to fuel supply through RA-2;	
411	no fuel in RA-2 Currently extraction from RA-1	Fuel empty at RA-2	Refill fuel at RA-2; Control switches to fuel supply through RA- 1;	
412	no fuel	Fuel empty at RA1 & RA2;	Refill fuel;	
413	no fuel in RA-1 Extraction changed to RA-2	Fuel empty at RA-1	Refill fuel at RA-1; Control switches to fuel supply through RA-2;	
414	no fuel in RA-2 Extraction changed to RA-1	Fuel empty at RA-2	Refill fuel at RA-2; Control switches to fuel supply through RA- 1;	
415	no fuel in RA-1	Fuel empty at RA-1;	Refill fuel at RA-1;	
416	no fuel in RA-2	Fuel empty at RA-2;	Refill fuel at RA-2;	
902	Fault memory has been initialised	no problem, only for protocol	no further actions; if this message occurs frequently please call	
903	Restart (Power ON)		the power supply; check connections between control and control boards; check all cables as well)	



No.	Origin	Reason / Problem	Solution (when done solving - push the Enter button)	
5210	Hardware test stoker auger failed	Stoker auger Neutral line not connected		
5220	Hardware test agitator failed	Room agitator RA-1 Neutral line not connected	Connect neutral line to motor star point or at the control bo (implicitly use 5-pole cable!); change the plug of the as	
5230	Hardware test ash auger failed	Ash auger Neutral line not connected	motor plug, if another error occurs, replace the motor or the supply, if the same error occurs - call service department	
5240	Hardware test connection auger failed	Connection auger Neutral line not connected	(temporary emergency operation possible, see "no hardware test" at the end of troubleshooting)	
5250	Hardware test agitator RA-2 failed	Room agitator RA-2 Neutral line not connected		
5310	Motor stoker auger not connected or fuse F4,F5,F6 defective	Motor cable supply or fuse F4,F5 or F6 defective		
5320	Motor agitator not connected or fuse F1,F2,F3 defective	Motor cable supply or fuse F1,F2 or F3 defective	check fuses and replace if needed (see stickers) or check	
5330	Motor connection auger not connected or fuse F7,F8,F9 defective	Motor cable supply or fuse F7,F8 or F9 defective	Exchange the alleged motor plug with another plug, if another error occurs the motor the supply is defective and must be changed: if the same error occurs the control board has to be	
5340	Motor ash auger not connected or fuse F10, F11 or F12 defective.	Motor cable supply or fuse F10,F11 or F12 defective	changed; call service department;	
5350	Motor agitator RA-2 not connected or fuse F7,F8,F9 defective	Motor cable supply or fuse F7,F8 or F9 defective		
5410	Exhaust fan not connected (only at pulse package control)	Cables, plugs or exhaust fan defective	Connect exhaust fan correctly (113/PE/N); Check plug for proper fit; call service department (temporary emergency operation possible, see "no hardware test" at the end of troubleshooting);	
5420	Ignition heater not connected	Cables, plugs or ignition defective	Connect ignition correctly (PE/N/118); Check plug for proper fit; call service department;	
5430	Stoker grate motor not connected	Cables, plugs or motor defective	Connect stoker grate motor correctly (114/PE/N/115); Check plug for proper fit; call service department (temporary emergency operation possible, see "no hardware test" at the end of troubleshooting);	
5440	Ash grate motor not connected	Cables, plugs or motor defective	Connect ash grate motor correctly (116/PE/N/117); Check plug for proper fit; call service department (temporary emergency operation possible, see "no hardware test" at the end of troubleshooting);	
5630	Fuse F14 defective			
5631	Fuse F15 defective	Fuse defective	check fuses and replace if needed (see stickers)	
5632	Fuse F16 defective			
6100	Supply phase sequence incorrectly	phases L1/L2/L3 are interchanged	Call electrician and connect phase sequence correctly; then check correct rotation of stoker, extraction and ash auger(s) in manual mode!	
6200	Supply phase is missing	Low voltage or blackout L2/L3 Fuse in meter box defective.	Supply and fuses to be checked by professional electrician; call service department, change control board.	
6301	STB triggered or not connected		Restart required; see No.001	
6313	Incorrect position of ash box		Restart required; see No.313	
6316	RA-lid open	After restort of the century hardware	Restart required; see No.316	
6318	Connection auger - lid open	test was not performed; sensor or	Restart required; see No.318	
6320	RA2-lid open	switch not connected;	Restart required; see No.320	
6328	Emergency stop has been operated		Restart required; see No.328	
6331	Safety switch storage room open		Restart required; see No.331	
9000	Firmware IO-board	After software update the control identified an obsolete firmware of IO-board	Update of firmware through service department;	

Errors No. 5210-5250 and No. 6300-6331 are only possible after restart of the control or operating the main switch



2.1 Temporary emergency operation (Restart without HW-test)

If the error is clearly a result of a defective control board, and the connected component works correctly; the control may be run in **temporary emergency operation** (until the service department arrives) without Hardware-Test.

- □ switch to operation mode "MANUAL" on the display
- navigate to the according manual parameter
- □ confirm <without HW-test>
- The Boiler operates with max. 60% heating output



Chapter X: Parameters

Parameters Manual operation level

	DANGER
	Inactive safety functions at mode "Manual"!
	 <manual> functions shall only be executed through trained personnel.</manual> Boiler must be in "OFF" mode. Ensure that there are no persons in the danger zone.
	This operation mode is only to:Check several electrical functionscheck equipment after errors manually!
	Scrolling in the menu through
	To activate the function hold button! Permanently active: Double click on button <on></on> or only at activated service level To exit the check: Press <off></off>
	To navigate menus ♣ only the latest chosen function is active ♣ Previous function will be inactive
lo. 1 Manual 0 U/min Neg. pressure 93 Pa Exhaust fan ON	 ☐ Functional check of exhaust fan ☑ Speed reached: ca. 3,500 rpm
Io. 2 Manual 0.0 A, Initiator DN Forward Backward 10 rounds + Grate 10 rounds	 Function and rotation check of ash extraction motor 10 rounds with (without) grate or manual forward or backward movement Press backward button only BRIEFLY Motor current range - see service level (Q11, Q12)
lo. 3 Manual 0.0 A gitator-1 Forward Backward	 Function and rotation check of storage room extraction motor (RA1) manual Forward and Backward of the motor to clear any blockages Press backward button only BRIEFLY Motor current range - see service level (R40, R41) for double - agitator, the additional parameter No. 3a is shown
lo. 4 Manual 0.0 A t oker auger Forward Backward	 Function and rotation check of ash stoker auger motor manual Forward and Backward, to fill the stoker auger Press backward button only BRIEFLY Motor current range - see service level (R10, R11)
lo. 5 Manual 0 mA connection auger Forward Backward	 Function and rotation check of connection auger motor (OPTIONALLY) manual Forward and Backward of the motor to clear any blockages Press backward button only BRIEFLY Motor current range - see service level (R50, R51)
lo. 6 Manual toker grate os 0° Forward Backward Close grate	 Function and rotation check of stoker grate motor Manual Forward or Backward of the motor at activated service level the calibration may be re-started at commissioning and after each maintenance



Х

1

Ν

N (

N A

N S

N C

N S F

No. 7 Manual Ash grate Pos 0° Forward Backward Close grate	 Function and rotation check of ash grate motor Manual Forward or Backward of the motor at activated service level the calibration may be re-started at commissioning and after each maintenance
No. 8 Manual Stoker grate / ash grate Pos 0°/0° Electricity 0mA/0mA Forward Backward	combined function- and rotation check of stoker grate and ash grate manual Forward or Backward of the motors
No. 9 Manual Firebed sensor Pos 75°/0.00V Offset 190° Calibration	 Calibration of firebed sensor only at activated service level
No.10 Manual Ra: 0.0A/Es: 0.0A Fill combustion chamber Start / RA1 Start / RA2	 at new start of the boiler, the empty augers may be refilled manually. prevents an error due to missing fuel
No. 11 Manual Ignition Ignition	 Function check of ignition After a maximum of 1 minute, the coil should be hot After 3 minutes the ignition coil switches off
No. 12 Manual Primary air flap SET: 0% IS: 0% OPE CLO	 Function and position check of the primary air flap (SET/IS) 100% - "OPEN"; 0% - "CLOSED" Position at both extremes 0% and 100% Press <open>, <closed></closed></open> Change of IS - value
No. 13 Manual Lambda-sensor Lambda Voltage/Correction 0.0/0.0 mV O2: 6.0% RGT: 160°C	 Calibrate lambda sensor (Duration approx. 5 minutes) Press <test start=""></test> ♦ After approx. 5 minutes the voltage of the sensor should be around -7.0 [mV] ♥ Values between -2 and -12 [mV] are in tolerance Calibrate lambda sensor (Duration approx. 15 minutes) ♥ only at activated service level remove lambda sensor and flue gas sensor Clean lambda sensor and screw-in sleeve Press <start calibration=""></start> ♦ After approx. 15 minutes the voltage of the sensor should be around -7.0 [mV] ♥ Values between -2 and -12 [mV] are in tolerance
	ΝΟΤΕ
	After the test: Tighten lambda sensor sufficiently Put flue gas sensor back in!
No. 14 Manual Ash suction	□ Function check of ash suction turbine (OPTIONALLY)







No. 26 Manual Horn TÜB (Temperature ON	Function check or short-term manual operation of the horn - TÜB
No. 30 Manual	Function check or short-term manual operation of HWS loading pump 1
HWS pump 1	In only at connected HKM 0 In order with the second sec
ON ON	# HWS pump A, 2 and 3 only at connected HKM A, HKM 1 and HKM 2
No. 31 Manual	Function check or short-term manual operation of HWS circulation pump 1
Circulation pump HWS 1	In only at connected HKM 0 In
ON	# HWS circulation pump A, 2 and 3 only at connected HKM A, HKM 1 and HKM 2
No. 32 Manual	Function check or short-term manual operation of heat circuit pump 1 carbon and a second sec
	 In the completed in the operation of the complete and the com
ON	# HWS pump A, 3 and 5 only at connected HKM A, HKM 1 and HKM 2
No. 33 Manual	Function and rotation check of mixer - heat circuit 1
	Inly at connected HKM 0 In No. 43, 53 and 63 for heat circuit mixer A. 3 and 5
	The term of term o
No. 34 Manual	□ Function check or short-term manual operation of heat circuit pump 2
Heat circuit pump 2	Inly at connected HKM 0
ON	HWS pump A, 4 and 6 only at connected HKM A, HKM 1 and HKM 2
No. 35 Manual Mixer beat circuit 2	□ Function and rotation check of mixer - heat circuit 2
OPE CLO	Inly at connected HKM 0
	Heat circuit mixer A, 4 and 6 only at connected HKM A, HKM 1 and HKM 2
No. 36 Manual	Function check or short-term manual operation of external heat circuit pump 1
	only at connected HKM U No. 56 and 66 for external heat circuit pump 2 and 3
	external heat circuit pump 2 and 3 only at connected HKM 1 and HKM 2
No. 70 - No. 74 Manual	Display of the current sensor values
Boiler sensor 72°C	acc. to parametrised heating system
Flue gas sensor 160°C	
Acc. temp. top 72°C	
Acc. temp. mid 56°C Acc. temp. bottom 30°C	



2 Installer level

- Enter the installer level with <Settings> <Installer>
 - □ access with code: 33



- ♦ You are now in the installer level.
 - Prior commissioning, all values must be checked by the installer and set according to the corresponding hydraulic scheme.

Mavigation:
For commissioning:

- Arrows key down: to parameters
- ♦ Selection of all parameters

For fast change of parameters

- press arrow key up: Short cuts
 - Short cuts to parameter sets:
 - A Heat circuits (A1, A2,...)
 - B HWS (B1, B2,...)
 - C Accumulator (C1, C2,...)
 - D General (D1, D2,....)
 - E Languages (E1)

2.1 Parametrisation of heat circuits and HWS:

- ☑ Extension module 0:
 - Heat circuit 1 (No. A1 No. A9)
 - Heat circuit 2 (No. A11 No. A19)
 - HWS 1 (No. B1 No. B8)
- ☑ Extension module 1:
 - Heat circuit 3 (No. A21 No. A29)
 - Heat circuit 4 (No. A31 No. A39)
 - HWS 2 (No. B11 No. B18)
- Extension module 2:
 - Heat circuit 5 (No. A41 No. A49)
 - Heat circuit 6 (No. A51 No. A59)
 - HWS 3 (No. B41 No. B48)

Heat circuit board (HC A)

- Heat circuit A (No. A61 No. A69)
- HWS 3A(No. B61 No. B68)
- The parameters of the extension module and the additional heat circuit board are only displayed when hardware is connected.





2.2 Parameter A - heat circuits:

<name></name>	
No. A1 Heat circuit 1	
Not available	
Pump	
Mixer	

No. A2 Heat circuit 1		
Steepnes Factory 1.6	1.6	

No. A3 Heat circuit 1 Flow temperature Minimum Factory:	30°C
No. A4 Heat circuit 1 Flow temperature Maximum Factory:	70°C

No. A5 Heat circ Mixer run time Factory: 90	uit 1 90 Sec
No. A6 Remote cor	ntrol
Not available	FR40 (digital)
FR25 (analogue)	
FR35 (digital)	

No. A6a Heat circuit 1 Remote
with room sensor
without room sensor
No. A6b HC1 Display remote
HWS A HWS 3
HWS 1 Accumulator
No. A6c HC1 Display remote
HC A HWS A Distr.I.
HC 1 HWS 1 Ext. HC
HC 2 Accumu- Error
No. A7 Heat circuit 1 District
no district line
District line 1
District line 2
No. A8 Heat circuit 1
Summer-bath heating
NO
YES

No. A9 Heat circuit 1 Screed

OFF
ON

No. A11,21,31,41,51 Heat circuit 2,3,4,5,6	
Not available	
Pump	
Mixer	

3 options:

- Heat circuit not available
- Heat circuit with pump
- Heat circuit with pump and mixer
- In No. A1 to <Not available> => No. A2 to No. A6 not displayed
- through pressing on <NAME> each heat circuit may be named separately (e.g.: Living room,...) Living room,...)

Describes the ratio between flow temperature change to outside temperature change (see chart - heat curve).

- @ Range: 0.2... 3.5
- Recommended settings:
 - Floor heating: 0.3... 1.0
 - Radiator: 1.2... 2.0
 - Convector: 1.5... 2.0

@ Change in small steps only and for a longer period

- Minimum limit for heat circuit 1 flow temperature.
 - The heating- or reduction mode, this flow temperature won't be underrun.
 - Range: 1... 80 [°C]

Maximum limit for heat circuit 1 flow temperature.

- The heating- or reduction mode, this flow temperature won't be overrun.
- Floor heating system: To avoid overheating of the floor heating system, an additional electro-mechanical thermostat must be installed, which interrupts the power supply to the associated heating circuit pump.

Numerical input of the actual value (see mixer type plate).

- Duration from closed to open condition
- Range: 10... 300 [s]

4 options:

- Heat circuit without remote control
- · Heat circuit with analogue remote control FR25
- Heat circuit with digital remote control FR35
- · Heat circuit with digital remote control FR40
- The remote control may be installed with or without room sensor.
- ⇒ see "Optional remote controls FR35 / FR40 (digital) and FR25 (analogue)" on page 26.

Setting, what should be shown on parametrised remote control FR35.

Setting, what should be shown on parametrised remote control FR40.

Activate district heat pump (1 or 2) when heat circuit pump 1 runs.

Activation of summer-bath heating function of the corresponding heat circuit.

- Heat circuit will be switched on (depending on timer settings) if accumulator is on temperature.
 - Is only activated in menu "HWS"

[©] if **<ON**> is selected, parameters **A8a - A8c** are displayed

Activation of screed heating function of the corresponding heat circuit.

- if <ON> is selected, parameters A9a A9f are displayed
- \Rightarrow see "Parameter list Installer" on page 57.

A11: Second additional heat circuit (on extension module 0)

A21, A31: If extension module 1 is used

A41, A51: If extension module 2 is used

A61: If heat circuit control board A is used

Range: See A1 "Heat circuit 1" - A9 "Heat circuit 1"



Installer parameters

2.3 Parameter B - HWS:

17		Not	availa	blo	
-11	YO.	ΡТ			

Not available	_
available	

No. B2 HWS 1 HWS temperature hvsteresis	6°C
Factory: 6°C	
NO. B23 HWS 1 HWS temperature	40°C
minimum Factory:	

No. B4 Legionella protection OFF ON No.B5 HWS 1 Legionella prot. Set temperature Factory: 70 °C No.B6 Legionella protection Weekly clock Mo Tu We Th Fr Sa Su a 17:00 --:-c 00:00 d ---:--No. B7 HWS 1 District line no district line District line 1 District line 2 No. B8 Circulation pump HWS 1 Not available Available No.B8a Circulation pump HWS 1 Run time 180 Sec No.B8b Circulation pump HWS 1 Down time 15 Min

No. B11 - B31 HWS 2,3 and A Not available Available

No. B60 HWS priority operation
OFF
ON
No. B90 Release all HWS
temp. Minimum
ON 06:00 ON:
OFF 22:00 OFF:

□ For heating systems with HWS 1, set to <available>

- Scontrol of HWS 1 activated
- Parameter No. B1 on <not available>
- ♦ also parameters HWS No. B2 to No.B4 are not displayed
- through pressing on <NAME> each heat circuit may be named separately (e.g.: Main house,...)
- Range: 1... 40 [°C]
- ⇒ see "HWS control" on page 21.

Lower HWS limit temperature.

- ✤ if HWS temperature underrun value set in the control, HWS loading starts.
 - ☞ within the time set (Parameter No. B90)
 - @ independent from HWS time programme (Customer level No. 1)
 - Range: 1... 80 [°C]

Activation of the Legionella protection programme

Range: 10... 75 [°C]

Sisk of burning if domestic hot water is not mixed

⇒ see "Legionella programme" on page 22.

Activate district heat pump (1,2) when HWS pump 1 runs.

Settings for circulation pump can be performed for each HWS parametrised in the control. ⇒ see "Circulation pump for hot water" on page 22.

Run time: The pump runs 180 [sec] and afterwards a downtime of 15 [min] follows until the next cycle.

The run time depends on the length of heating lines and on the heat loss in the lines. (Insulation)

B11: If extension module 1 is used B21: If extension module 2 is used B31: If heat circuit control board **A** is used Range: See **B1 "HWS 1" - B9 "HWS 1"**

⇒ see "HWS-priority control" on page 24.

```
HWS loading time outside of "HWS Day-Week clock (No. 1)

☞ if HWS temperature below value set (Parameter No. B3)

⇒ see "HWS control" on page 21.
```



Χ

2.4 Parameter C - Accumulator

Bypass pump R-Mixer+R-Pump R-Mixer+DH-P.1	
R-Mixer+DH-P.1	
R-Mixer+Acc.	

Mixer run time (Kp) Factory: 140 <mark>140 Se</mark>	No. C1b Return mixer	
Factory: 140 140 Se	Mixer run time (Kp)	
	Factory: 140	140 Se

No. C2 Accumula	tor
not available	Accumulator with
Acc. with heat	Accumulator with
Accumulator with	

No. C3 Accumulator

Accumulator/

HWS

Accumulator/HWS

externally

Accumulator sensor

Accumulator sensor

Accumulator sensor

HWS sensor 2

No. C3a Accumulator

4 setting possibilities: acc. to hydraulic scheme

- Bypass pump
- Return mixer with district heating pump 1
- · Return mixer with accumulator loading pump
- · Return mixer with return pump (low loss header)

Enter actual mixer run time

- Duration from closed to open condition
- @ Range: 10... 300 [s]
- 5 setting possibilities: acc. to hydraulic scheme
 - not available
 - Accumulator with heat circuit valve
 - ♦ for low-temperature heat circuits (e.g.: floor- or wall heating circuits)
 - Accumulator with one sensor
 - At hydraulic scheme HP3 with accumulator unloading control
 - Accumulator with two sensors
 - ♦ at hydraulic scheme **HP4** with accumulator loading and unloading control
 - Accumulator with three sensors
 At hydraulic scheme HP5 with accumulator loading (part load operation) and unloading control
- 2 setting possibilities: acc. to hydraulic scheme
 - Accumulator/HWS integrated
 - Accumulator with integrated HWS
 - (Domestic hot water coil or external hot water heat exchanger)
 - Accumulator with external HWS
 - for existing differential control between accumulator and HWS set: "Accumulator / HWS integrated"

4 setting possibilities: acc. to hydraulic scheme

- for existing accumulator and extension module, the acc. sensor assignment may be chosen
 - Acc. in the boiler room => Choose <Accumulator sensor Boiler>
 - Acc. next door (HKM) => Choose <Accumulator sensor HKM1/2>

4 setting possibilities: acc. to hydraulic scheme

- - Parameter No. C3 <Acc/HWS internally>

Setting the acc.-set temperature

- Displays only, if parameter C2 is set to <Acc. with 2 sensors> or <Acc. with 3 sensors>
 - If heat is requested, the accumulator is by default loaded to C4 = 60 [°C] (sensor 2 bottom)
 - @ Range: 20... 80 [°C]

Adjusting the boiler set temperature at acc. loading

- Displays only, if parameter C2 is set to <Acc. with 2 sensors> or <Acc. with 3 sensors>
 - At acc. loading with 2 or 3 sensors, the **boiler** operates at the temperature C4a = 78 [°C]
 - Range: 20... 100 [°C]
- <Setting times for forced accumulator loading
- Displays only, if parameter C2 is set to <Acc. with 2 sensors> or <Acc. with 3 sensors>
 - Acc. forced loading at set times and activated set temperature C4 = 60 [°C] (Accumulator sensor bottom)
 - @ e.g. for peak loads in the morning (e.g. 4am 10am)

No. C3b Accumu	lator
HWS sensor A	HWS sensor 3
HWS sensor 1	

Accumulator

No. C4	
Switch off temperature	60%
acc. sensor bottom	00 0

No. C4a Accumulator Boiler set temperature at accumulator loading Factory: 78°C

No. C4 Accumulator			
ON	:	ON	:
OFF	:	OFF	:



No. C6a External heat	circuit
external heat circuit set	60%
temperature	09 0
Factory: 69°C	

No.C7 Function pump exit

(District heating pump 2)
external pump

No. C8 External heat circuit and
no district line

Set, if t	the external heat circuit is referred to the district heating pump 1	1 or 2	2
₿ 1	District heating pump runs if one of the referred pumps run		

Boiler is heated to the temperature set in parameter C6a

Adjusting the boiler set temperature at activated external heat circuit

service-parameter L5 = 50 [°C] has to be adjusted

@ L5 ca. 5 - 10 [°C] less than C6a

2 setting possibilities: acc. to hydraulic scheme

parametrised to "district heating")

• External heat circuit pump

District heating pump

if the value is changed and parameter C7 is set to <external pump>, also the

external heat circuit pump is switched on at release temperature (Parameter

 \checkmark District heating pump runs, if a heat circuit - or HWS pump switches on (and is

No. C9 External heat

with district line 1 with district line 2

	not available	
C	Oil/Gas	
	Solid fuel	

2.5 Parameter D - General

No. D1a HKM 0 Display HC A HWS A Distr.l. HC 1 HWS 1 Ext. HC HC 2 Accumu- Error
No. D2 frost protection Pump on if outs. temp. below Factory: 1 °C
No. D3 frost protection Flow-Set temperature Factory: 7°C 7°C
No.D5 Switch day-reduction mode ON 06:00 OFF 22:00
No. D6a Ash suction

without ash bin	
	_

No. D6b Rele	ease ash suction
ON 06:00	ON:
OFF 22:30	OFF:

No. D6r Release de-ash wood chip		
ON 06:00	ON:	
OFF 22:30	OFF:	

Selection regarding display possibilities at connected HKM 0

Parameter No. D1b at connected HKM 1

3 setting possibilities: acc. to hydraulic scheme

Parameter No. D1c at connected HKM 2

Outside temperature below set value

All heat circuit pumps on (mixer is "Closed")

Heat circuits with mixer are controlled to temperature No. D3.

 \Rightarrow see "Frost protection" on page 25.

Flow temperature (for heat circuits with mixer) under set value ♣ "Open" mixers of heat circuits

Switch point, at which time the logic changes from night- to day settings. (Parameter 12,13)

⇒ see "Outside temperature - Shut down" on page 24.

3 options:

- not available
- Ash suction with ash bin
- Ash suction without ash bin

The fully automatic ash suction process will be performed within the set time ritating noise during the de-ash or cleaning

The automatic de-ash and cleaning process is executed only within the set times depending on parametrised fuel

- Wood chips => D6r
- Pellets => D6s
- Miscanthus => D6t
- irritating noise during the de-ash or cleaning



Х

S

 not available Oil- / Gas- boiler Solid fuel - boiler

٠

L5)

No. D7 all heat circuits Summer switch off - hold time Factory: 120 (120 Min)	Summer switch off: Outside temperature falls below 16°C (Parameter No.11) If the time to shut down the boiler (reduction) is now shorter than 2 hours the boiler does not start
No. D8 Daylight saving time no autom. switch autom. switch	change clock automatically from daylight saving time to winter time.
No. D9 Day clock / Week clock Day clock Week clock HC+HWS week clock	 Display day- or week clock in the customer level. ⇒ see "Menu "Week clock", "Day clock"" on page 20. ☞ Day-clock: Heat circuits and HWS on day clock ☞ Week-clock: Heat circuits on week clock, HWS on day clock ☞ HC+HWS week clock: Heat circuits and HWS on week clock
No. D10 Number of blocks for week clock Factory: 2 2	Number of blocks to set for week clock in the customer level. @ Range: 1 7
No. D11 Holiday mode released NO YES	activates the holiday mode for the time set at parameter - Customer level No.16 all heat circuits together or separated (Parameter No. D11a)
No.D12 Outside temperature shutdown separately all HC together	Outside temperature thresholds to set separately for each heat circuit. Identical thresholds for all heat circuits ⇒ see "Outside temperature - Shut down" on page 24.
No.D13 Outside sensor Not available Available	no outside sensor required
No.D20 ETÜ Not available Available	The stoker auger - temperature monitoring (ETÜ) is parametrised by default
No.D21 TÜB Not available Available	If a temperature monitoring of the fuel storage room (TÜB) is required (depending on state law and regulation) this has to be activated Parameter No. D21a at double-RA
No.D22 Double Agitator Switch over time Factory: 300 300 Min	Setting, after how many minutes the agitator switches to the other agitator

2.6 Parameter E - languages

Language	
German	
French	
Italian	
English	
Spanish	

Selection of the desired language (optionally) German

3 Parameter list - Customer

Reset to factory settings:

<Settings> - <Service level> - <Special feat.> - <No. Z4 Load factory settings>

Menu	Description	Factory	ls	ls
Extensio	n module 0			
No.1	HWS 1 Day clock	ON 17:00 00:00		
to parame	trise "Week clock" (menu no. D9 in installer setting	s)		
		Mo Tu We Th Fr Sa		
No 1o		So		
No.1a	HWS1	ON 17:00 00:00		
		OFF 20:00 00:00		
No.1b	HWS 1	all off		
No.2	HWS 1 Set temperature	60°		
No. 2a	HWS 1 circulation pump	ON 17:00 00:00		
	· ·	OFF 20.00 00.00		
No.3	Heat circuit 1 Day clock	OFF 09:00 22:00		
to parame	etrise "Week clock" (menu no. D9 in installer setting	s)		
		MoTuWeThFrSa		
No.3a	Heat circuit 1	ON 06:00 15:00		
		OFF 09:00 22:00		
No.3b	Heat circuit 1	ON 06:00 00:00		
		OFF 22:00 00:00		
No.4	Heat circuit 1 Day-room temp.	20° C		
No.5	Heat circuit 1 Reduction-room temp.	16° C		
No.6	Heat circuit 2 Day clock	ON 06:00 15:00 OFF 09:00 22:00		
to parame	etrise "Week clock" (menu no. D9 in installer setting	s)		
		Mo Tu We Th Fr Sa		
No.6a	Heat circuit 2	So ON 06:00 15:00		
		OFF 09.00 22.00		
No.6b	Heat circuit 2	ON 06:00 00:00		
		OFF 22:00 00:00		
No.7	Heat circuit 2 Day-room temp.	20° C		
No.8	Heat circuit 2 Reduction-room temp.	16° C		
Heat circ	uit board A			
HP 1	HWS A day clock	ON 17:00 00:00		
		OFF 20:00 00:00		
HP 2	HWS A Set temperature	00 ⁻		
HP 3	HWS A Day clock	OFF 09:00 22:00		
HP 4	Heat circuit A Day-room temp	20°		
HP 5	Heat circuit A Reduction-room temp	16°		
Extensio	n module 1			
		ON 17:00 00:00		
HI	HWS 2 Day clock	OFF 20:00 00:00		
H 2	HWS 2 Set temperature	60°		
Н3	Heat circuit 3 Day clock	ON 06:00 15:00 OFF 09:00 22:00		
H 4	Heat circuit 3 Day-room temp.	20°		
H 5	Heat circuit 3 Reduction-room temp.	16°		
H 6	Heat circuit 4 Day clock	ON 06:00 15:00 OFF 09:00 22:00		
H 7	Heat circuit 4 Day-room temp.	20°		
H 8	Heat circuit 4 Reduction-room temp.	16°		
	•		L	



Exte	Extension module 2								
L 1/	1	HWS 3 Day clock	ON 17:00 00:00						
			OFF 20:00 00:00	OFF 20:00 00:00					
H 12	2	HWS 3 Set temperature	60°						
H 13	3	Heat circuit 5 Day clock	ON 06:00 15:00						
			OFF 09:00 22:00						
H 14	1	Heat circuit 5 Day-room temp.	20°						
H 15	5	Heat circuit 5 Reduction-room temp.	16°						
Н 16	3	Heat circuit 6 Day clock	ON 06:00 15:00						
	, 	Theat circuit o Day clock	OFF 09:00 22:00						
H 17	7	Heat circuit 6 Day-room temp.	20°						
H 18	3	Heat circuit 6 Reduction-room temp.	16°						
If "O	utside	e temperature shut down - separated" is chosen (nstaller level No. D12), d	ifferent temperatures	s per heat circuit may				
be s	et.		-						
No.	11	Heating off at outside temperature over	16°						
No.	12	Heating off at day reduct. outside temp. over	8°						
No.	13	Heating off at day reduct. outside temp. over	-5°						
Thro	bugh p	parametrisation "Outside temp. Day/N." (Service le	vel No. M10) also for exte	rnal heat circuits, out	side temp. shut down				
may	be se	et.							
No.	15	Holiday mode	not active						
No.	16	Holiday mode	from to						
No.	18	Ash suction	not active						
No.	19	Fuel	Wood chips						
No.	19a	Extraction system	equal emptying						
No.	20	Date / Time							
No.	21	Release remote maintenance	not released						
No.	21a	autom. deactivation of release	10 Min.						



4 Parameter list - Installer

Installer-settings (Settings / Installer / Code33)

	N	lenu	Description	Factory	ls		Ν	lenu	Description	Factory	ls
	Α	1	Heat circuit 1	not avail.			A	31	Heat circuit 4	not avail.	
	A	2	HC 1 steepness	1.60			A	32	HC 4 steepness	1.60	
	A	3	HC 1 flow temp. Min	30°			A	33	HC 4 flow temp. Min	30°	
	A	4	HC 1 flow temp. Max.	70°		4	A	34	HC 4 flow temp. Max.	70°	
	A	5	HC 1 mixer run time	90s		cuit	A	35	HC 4 mixer run time	90s	
	A	6	Remote HC1	not avail.		circ	A	36	Remote HC4	not avail.	
-	Α	7	HC1 district line	no dl		eat	A	37	HC4 district line	no dl	
cuit	Α	8	Summer-bath heating HC1	off		Т	A	38	Summer-bath heating HC4	off	
cir	A	9	Screed hea. HC1	off			A	39	Screed hea. HC4	off	
Heat	Α	9a	Screed hea. HC1 Flow-rise	5°C			A	39a - 39f	Screed hea. Parameter HC4	acc. factory set.	
	А	9b	Screed hea. HC 1 Flow-set reduction	10°C			Α	41	Heat circuit 5	not avail.	
	Α	9c	Screed hea. HC1 rise after	1 day(s)			A	42	HC 5 steepness	1.60	
	A	9d	Screed hea. HC1 Flow-Min.	20°C			A	43	HC 5 flow temp. Min	30°	
	Α	9e	Screed hea. HC1 Flow-Max.	45°C		lit 5	Α	44	HC 5 flow temp. Max.	70°	
	A	9f	Screed hea. HC1 hold time	4 day(s)		ircu	A	45	HC 5 mixer run time	90s	
	A	11	Heat circuit 2	not avail.		at ci	Α	46	Remote HC5	not avail.	
	Α	12	HC 2 steepness	1.60		He	Α	47	HC5 district line	no dl	
	Α	13	HC 2 flow temp. Min	30°			A	48	Summer-bath heating HC5	off	
2	A	14	HC 2 flow temp. Max.	70°			A	49	Screed hea. HC5	OFF	
rcuit	Α	15	HC 2 mixer run time	90s			A	49a - 49f	Screed hea. Parameter HC5	acc. factory set.	
at ci	A	16	Remote HC2	not avail.			A	51	Heat circuit 6	not avail.	
Hea	Α	17	HC2 district line	no dl			Α	52	HC 6 steepness	1.60	
	А	18	Summer-bath heating HC2	off			Α	53	HC 6 flow temp. Min	30°	
	A	19	Screed hea. HC2	off		9	A	54	HC 6 flow temp. Max.	70°	
	А	19a - 19f	Screed hea. Parameter HC2	acc. factory set.		ircuit	A	55	HC 6 mixer run time	90s	
	A	21	Heat circuit 3	not avail.		at ci	A	56	Remote HC6	not avail.	
	Α	22	HC 3 steepness	1.60		He	A	57	HC6 district line	no dl	
	Α	23	HC 3 flow temp. Min	30°			A	58	Summer-bath heating HC6	off	
e	A	24	HC 3 flow temp. Max.	70°			A	59	Screed hea. HC 6	off	
ircuit	Α	25	HC 3 mixer run time	90s			A	59a - 59f	Screed hea. Parameter HC6	acc. factory set.	
at c	A	26	Remote HC3	not avail.			A	61	Heat circuit A	not avail.	
He	A	27	HC3 district line	no dl			A	62	HC A steepness	1.60	
	Α	28	Summer-bath heating HC3	off			A	63	HC A flow temp. Min	30°	
	A	29	Screed hea. HC3	off		A	A	64	HC A flow temp. Max.	70°	
	A	29a - 29f	Screed hea. Parameter HC3	acc. factory set.		rcuit	A	65	HC A mixer run time	90s	
						nt ci	Α	66	Remote HC A	not avail.	
						Hea	Α	67	HC A6 district line	no dl	
							A	68	Summer-bath heating HC A	off	
							A	69	Screed hea. HC A	off	



A 69a - 69f

А

Screed hea. Parameter HC

acc. factory

set.

	N	lenu	Description	Factory	ls
	В	1	HWS 1	available	
	В	2	HWS 1 temp. switch difference	6°	
	В	3	HWS 1 temperature minimum	40°	
-	В	4	Legionella protection	OFF	
SN	В	5	Legionella prot. Set temp.	70°	
Ŧ	В	6	Legionella prot. release temp.	Mo - 17:00	
	В	7	HWS 1 district line	no dl	
	В	8	Circulation pump HWS 1	not avail.	
	В	8a	Circulation pump - run time	180s	
	В	8b	Circulation pump - stop time	15min	
	В	11	HWS 2	not avail.	
	В	12	HWS 2 temp. switch difference	6°	
	В	13	HWS 2 temperature minimum	40°	
S 2	В	14	Legionella protection	OFF	
МH	В	15	Legionella prot. Set temp.	70°	
	В	16	Legionella prot. release temp.	Mo - 18:00	
	В	17	HWS 2 district line	no dl	
	В	18	Circulation pump HWS 2	not avail.	

	N	lenu	Description	Factory	ls
	В	21	HWS 3	not avail.	
	В	22	HWS 3 temp. switch diff.	6°	
~	В	23	HWS 3 temperature minimum	40°	
S	В	24	Legionella protection	OFF	
Ŧ	В	25	Legionella prot. Set temp.	70°	
	В	26	Legionella prot. rel. temp.	Mo-19:00	
	В	27	HWS 3 district line	no dl	
	В	28	Circulation pump HWS 3	not avail.	
	В	31	HWS A	not avail.	
	В	32	HWS A temp. switch diff.	6°	
	В	33	HWS A temp. minimum	40°	
S A	В	34	Legionella protection	No	
Š	В	35	Legionella prot. Set temp.	70°	
-	В	36	Legionella prot. rel. temp	Mo - 17:00	
	В	37	HWS A district line	no dl	
	В	38	Circulation pump HWS A	not avail.	

-A	В	60	HWS - priority control	ON	
HWS 1	В	90	Release all HWS temp. Min.	06:00-22:00	

	Menu		Description	Factory	ls
	D	1a,b ,c	HKM 0, 1, 2 - Touch Display	Selection- window	
	D	2	Frost prot. Pump on under Outs.temp.	1°	
	D	3	Frost prot. Flow set temp.	7°	
	D	5	Changeov. Day-reduction	06:00-22:00	
	D	6a	Ash suction	not avail.	
	D	6b	Release ash suction	06:00-22:30	
	D	6r,s, t	Release deash Wood chips, Pellets, Miscanthus	06:00-22:30	
le	D	7	HC 1-6 summer shut down. blocking time	120min	
Senera	D	8	Daylight saving time - auto switch	Auto	
0	D	9	Day- / Week clock	Day-clock	
	D	10	Dis. Blocks for week clock	2	
	D	11	Release holiday mode	No	
	D	11a	Holiday mode	all HC	
	D	12	Outside temp Shut down	all HC	
	D	13	Outside sensor	not avail.	
	D	D 20 ETÜ-Stoker auger temp. monitoring		available	
	D	21	TÜB-Temperature monitoring fuel storage room	not avail.	
	D	22	Add. function	not avail.	
	Е	1	Language	German	

				F a a b a	
_	N	lenu	Description	Factory	Is
		4 -	De als and anota attain	Return-	
	Ч	1a	Back end protection		
	\vdash			Accpullip	
	С	1b	Return mixer run time	90s	
	С	2	Acc. or external operation	not avail.	
	С	3	Accumulator-HWS	externally	
	С	3a	Accumulator-sensor	Boiler	
nulator	С	4	Switch off temperature acc. sensor bottom	60°	
ccun	С	4a	Acc. loading boiler set temp.	78°	
◄	С	5	Forced acc. loading / day clock	00:00	
	С	6a	Boiler set temp. external HC	69°	
	С	7	Pump exit (Ext/ Dist.HeaPump 2)	not avail.	
	С	8	Ext. HC at Distr.heapump	no dl	
	С	9	External heat	not avail.	
		Info	Description	Value	Value
			Operation hours Control		
			Operation h. HEATING SYS.		
			Operation h. Ignition		
			Operation h. Exhaust fan		
			Operation h. Stoker		
			Operation h. Agitator		
			Number of de-ash cycles		



5 Parameter list - Service

Values in (...) are for ECO-HK 40-60

Menu	1	Description	Factory	Menu	Description	Factory
Σ	J1	Waiting time SMS alert	5 Min	J3	Time to clear	10 Min
J - GS	J2	GSM-Module Reset	No	J4	Auto Reset GSM	Auto Reset GSM
	K1	Boiler compustion - min heat output	50 %	K14	Boiler flue gas temp, error under	70 °C
	K2	Regulator - max_output at combustion	100 %	K15	Boiler time flue gas temp, error	15 Min
	K3r	Boiler exhaust fan speed 100% output wood chips	see list below	K20	Boiler TÜB max. temp. fuel storage room	60 °C
	K3s	Boiler exhaust fan speed 100% output pellets	see list below	K21	Boiler ETÜ max. temp. stoker auger	50 °C
Boiler	K3t	Boiler exhaust fan speed 100% output miscanthus	see list below	K29	Boiler max. control board temperature exceeded	60 °C
× ·	K10	Boiler min. temperature with bypass	75 °C	K30	Boiler chimney sweep set temperature	78 °C
	K10a	Boiler minimum temperature	78 °C	K31	Boiler chimney sweep run time	120 Min
	K11	Boiler maximum temperature	85 °C	K32	Boiler chimney sweep max. heat output - full load	100 %
	K12	Boiler temperature switch difference	6 °C	K32a	Boiler chimney sweep max. heat output - partial load	50 %
	K13	Boiler set temperature superelevation	4 °C	K40	Boiler output limit at error	60 %
		D				
	L1	Pumps district line pump 1 release temperature	58 °C	L7	Pumps HWS pump 2 release temp.	63 °C
	L2	Pumps district line pump 2 release temperature	59 °C	L7a	Pumps HWS pump 3 release temp.	62 °C
	L3	Pumps heat circuit pump 1 release temperature	60 °C	L7b	Pumps HWS pump A release temp.	63 °C
	L4	Pumps heat circuit pump 2 release temperature	61 °C	L10	Return Minimum	58 °C
	L4a	Pumps heat circuit pump 3 release temperature	62 °C	L10a	Return differential	see list below
	L4b	Pumps heat circuit pump 4 release temperature	63 °C	L10b	Return differential Auto-adjust range	0
	L4c	Pumps heat circuit pump 5 release temperature	62 °C	L10c	BEP pump release temperature	52 °C
	L4d	Pumps heat circuit pump 6 release temperature	63 °C	L11	Pumps Back end protection error under	50 °C
Pumps	L4e	Pumps heat circuit pump A release temperature	62 °C	L12	Return time for error back end protection	60 Min
÷	L4i	Pumps heat circuit pump 1 release temperature	30 °C	L12a	Return return mixer interval	10 Sec
	L4j	Pumps heat circuit pump 2 release temperature	31 °C	L12b	Return mixer reset time (Tn)	15 Sec
	L4k	Pumps heat circuit pump 3 release temperature	32 °C	L12c	Return mixer run time	0.8 Sec
	L4I	Pumps heat circuit pump 4 release temperature	33 °C	L12d	Open return mixer at first start up	17 %
	L4m	Pumps heat circuit pump 5 release temperature	32 °C	L13	Type of BEP-pump	HE-pump
	L4n	Pumps heat circuit pump 6 release temperature	33 °C	L20	Return controller RL-Set Kp	1
	L4o	Pumps heat circuit pump A release temperature	32 °C	L21	Return controller RL-Set Tn	1000 Sec
	L5	Pumps external heat circuit release temperature	64 °C	L22	Return controller RL-Set Tv	0 Sec
	L6	Pumps HWS pump 1 release temp.	62 °C	L24	Return Acc mid set	60 °C



Mrt. ellihead circuids - pumps on if bolier 92 °C M8 Heat circuid 1 min. mixer run time 0.3 Sec Mass ellihead circuids - outside temperature for solute bolier 0.0 °C M8 Heat circuid 1 min. mixer run time 0.3 Sec Mass all head circuids - outside temperature for solute bolier 0.0 °C M8 Heat circuid 3 min. mixer run time 0.3 Sec Mass all head circuids - bolier superelevation after flow (emp). 10 °C M8 Heat circuid 5 min. mixer run time 0.3 Sec Mass Heat circuid 5 min.mixer run time 0.3 Sec 0.3 Sec 0.3 Sec Mass Heat circuid 5 min.mixer run time 0.3 Sec 0.3 Sec Mass Heat circuid 1 minuene factor remote 1 M9 Heat circuid 6 min.mixer run time 0.3 Sec Mass Heat circuid 1 minuene factor remote 1 M10 Resented HC M100 Resented HC Mass Heat circuid 1 minuene factor remote 1 M12 all heat circuid 1 minuene factor remote 1 M12 all heat circuid 1 minuene factor remote 1 M12 all heat circuid 1 minuene factor remote	Menu	!	Description	Factory	Menu	Description	Factory
Ministry Immerature over Description Outcome of the second se		M1	all heat circuits - pumps on if boiler	02 °C	M8	Heat circuit 1 min, mixer run time	0.3 Sec
Mina all head circuits - outside temperature for advert below -10 °C Mg Heat circuit 2 min. mixer run time 0.3 Sec Mina all head circuits - residual heat use unit of the below 40 °C Mga Heat circuit 3 min. mixer run time 0.3 Sec Mga Heat circuit - influence factor remote control 10 °C Mgb Heat circuit 6 min. mixer run time 0.3 Sec Mga Heat circuit 5 min.mixer run time 0.3 Sec Mga Heat circuit 5 min. mixer run time 0.3 Sec Mga Heat circuit 5 min.mixer run time 0.3 Sec Mga Heat circuit 5 min.mixer run time 0.3 Sec Mga Heat circuit 5 min.mixer run time 0.3 Sec Mga Heat circuit 5 min.mixer run time 0.3 Sec Mga Heat circuit 6 min.mixer run time 0.3 Sec Mga Heat circuit 6 min.mixer run time 0.3 Sec Mga Heat circuit 6 min.mixer run time 0.3 Sec Mga Heat circuit 6 min.mixer run time 0.3 Sec Mga Heat circuit 6 minuence factor remote 1 Mfa all heat circuits minuence factor remote 1 Mfa Heat circuit 6 minuence factor remote			temperature over	92 0	IVIO		0.3 360
M2 Bill heat circuits - nesidual heat use until M3 All heat circuits 3 min. mixer run time 0.3 Sec M3 all heat circuits - boller superelevation and the tow samp. 10 °C M8b Heat circuit 4 min. mixer run time 0.3 Sec M4 Heat circuit 2 minunce factor remote control 1 M8c Heat circuit 5 min. mixer run time 0.3 Sec M5 Heat circuit 2 minunce factor remote control 1 M8d Heat circuit 3 min. mixer run time 0.3 Sec M5 Heat circuit 3 minunce factor remote control 1 M8d Heat circuit 3 min. mixer run time 0.3 Sec M65 Heat circuit 4 minunce factor remote control 1 M10 external HC without outs. second M65 Heat circuit 6 minunce factor remote control 1 M11 all heat circuits formation release difference 0 °C M65 Heat circuit 8 minunce factor remote control 1 M20 all HW3 - balar superelevation legionella protection Sec M7 all HW3 - balar superelevation delay 1 °C N5 all HW3 - balar superelevation at HW3 10 °C M8 Heat circuit 4 minunce factor monte control		M1a	all heat circuits - outside temperature for safety circuit	-10 °C	M9	Heat circuit 2 min. mixer run time	0.3 Sec
Mag all heat circuits - boiler superelevation and the source of the source		M2	all heat circuits - residual heat use until boiler below	40 °C	M9a	Heat circuit 3 min. mixer run time	0.3 Sec
Mag Heat circuit 1 influence factor remote control 1 MBc Heat circuit 5 min. mixer run time 0.3 Sec M5 Heat circuit 2 influence factor remote control 1 MBd Heat circuit 6 min. mixer run time 0.3 Sec M5 Heat circuit 3 influence factor remote control 1 MBd Heat circuit 4 min. mixer run time 0.3 Sec M6 Heat circuit 4 influence factor remote control 1 M10 external HC without outs. temp. M66 Heat circuit 5 influence factor remote control 1 M11 all heat circuits proportional coefficient 100 % M56 Heat circuit 5 influence factor remote control 1 M22 all heat circuits proportional coefficient 100 % M66 Heat circuits influence factor remote control 1 M20 all heat circuits mixer reduction release difference 0 °C N5 all heat circuits mixer reduction release difference 0 °C N6 all heat circuits mixer reduction release difference 0 °C N6 all HWS - bidiference temp. 5 °C N2 all HWS - hot water storage priority all HWS - bidiference temp. 5 °C O8 all HWS -		МЗ	all heat circuits - boiler superelevation after flow temp.	10 °C	M9b	Heat circuit 4 min. mixer run time	0.3 Sec
Ms Heat circuit 2 influence factor remote control 1 M8d Heat circuit 4 min. mixer run time 0.3 Sec 0.3 Sec MsD Heat circuit 3 influence factor remote control 1 M9e Heat circuit 4 min. mixer run time 0.3 Sec MsD Heat circuit 3 influence factor remote control 1 M9e Heat circuit 3 minuene factor remote control 1 M10 external HC without outs. temp. MsD Heat circuit 3 influence factor remote control 1 M11 all heat circuits differential temp. for mixes 1°C Msd Heat circuit 3 influence factor remote control 1 M20 all heat circuits mixer reduction release or C 0 °C M1 all heat circuits reduction delay 15 Min All heat circuits reduction delay 1 °C N6 all HWS - boter superelevation legionella protection 5 °C N2 all HWS - hot water storage priority oricuit factor 1 °C N6 all HWS - boter superelevation at HWS 10 °C N2 all HWS - hot water storage priority oricuit factor 1 °C N6 all HWS - boter superelevation at HWS 10 °C O1 Acc. superelevation heat cir	lits	M4	Heat circuit 1 influence factor remote control	1	M9c	Heat circuit 5 min. mixer run time	0.3 Sec
M5 Mate interventional sufficience factor remote control 1 M9e Heat circuit A min. mixer run time 0.3 Sec M6b Heat circuit 3 influence factor remote control 1 M10 external HC without outs. temp. M6b Heat circuit 3 influence factor remote control 1 M11 all heat circuits proportional coefficient 100 %. M66 Heat circuit 3 influence factor remote control 1 M12 all heat circuits differential temp. for mixers 1 °C M66 Heat circuit 3 influence factor remote control 1 M20 all heat circuits mixer reduction release 0 °C M7 all HWS - hot water storage pump on at outs. temp. over 90 °C N5 all HWS - boiler superelevation serveral time several time several time function factor throms 10 °C N2 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C N4 all HWS - Hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C N3 aci HWS - High serveration HMS set temp. 5 °C O3 Acccunulator HWS difference temp.	at circı	M5	Heat circuit 2 influence factor remote control	1	M9d	Heat circuit 6 min. mixer run time	0.3 Sec
M6b Heat circuit 3 influence factor remote control 1 M10 external HC without outs. temp. M5c Heat circuit 5 influence factor remote control 1 M11 all heat circuits proportional coefficient invers 100 % M5c Heat circuit 6 influence factor remote control 1 M12 all heat circuits differential temp. for mixers 1 °C M5e Heat circuit A influence factor remote control 1 M20 all heat circuits mixer reduction release difference 0 °C M7 all heat circuits reduction delay 15 Min - - - N1 all HWS - hot water storage pump on at outs. temp. over 90 °C N5 all HWS - boiler superelevation legionelia protection 5 °C N2 all HWS - hot water storage priority oricuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C N4 all HWS - hot water storage priority oricuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C N4 all HWS - hot water storage priority oricuit factor 1 N7 all HWS - hot water storage priority oricuit factor 1 N7 all H	M - He	M5a	Heat circuit 3 influence factor remote control	1	M9e	Heat circuit A min. mixer run time	0.3 Sec
M5c Heat circuit 5 influence factor remote control 1 M11 all heat circuits groportional coefficient 100 % M6d control 1 M12 all heat circuits differential temp. for mixers 1 °C M5e Heat circuits influence factor remote control 1 M20 all heat circuits mixer reduction release of C 0 °C M7 all heat circuits reduction delay 15 Min		M5b	Heat circuit 4 influence factor remote control	1	M10	external HC	without outs. temp.
M5d Heat circuit 6 influence factor remote control 1 M12 all heat circuits differential temp. for mixers 1 °C M6e Heat circuit A influence factor remote control 1 M20 all heat circuits mixer reduction release difference 0 °C M7 all heat circuits reduction delay 15 Min		M5c	Heat circuit 5 influence factor remote control	1	M11	all heat circuits proportional coefficient	100 %
Mse Heat circuit A influence factor remote control 1 M20 all heat circuits mixer reduction release difference 0 °C M7 all heat circuits reduction delay 15 Min N1 all heat circuits reduction delay 15 Min S°C S°C S°C S°C Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time Several time		M5d	Heat circuit 6 influence factor remote control	1	M12	all heat circuits differential temp. for mixers	1 °C
M7 all heat circuits reduction delay 15 Min Image: Constraint of the second		M5e	Heat circuit A influence factor remote control	1	M20	all heat circuits mixer reduction release difference	0 °C
N1 all HWS - hot water storage pump on at outs. temp. over 90 °C N5 all HWS - boiler superelevation legionella protection 5 °C N2 all HWS - difference temp. for HWS pump 1 °C N6 all HWS Residual heat several time N3 all HWS - tot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS loading 10 °C N4 all HWS - HWS pump after run time res. heat 5 °C 0 0 Acc. superelevation heat circuit set temp. 02 5 °C 08 Accumulator fill level reference temp. 03 75 °C 01 Acc. superelevation heat circuit set temp. 03 5 °C 09 Accumulator HWS difference control 0N 0N 03 Acc. superelevation HWS-Set temp. 04 5 °C 01 External heat differential 2 °C 04 Acc. superelevation HWS-Set temp. 05 1 °C 01 External heat differential 2 °C 04 Acc. difference temp. 05 5 °C 01 External heat differential 2 °C 05 Acc. difference temp. 07 5 °C 013 Accumulator fill evelas ternsi 30 °C		M7	all heat circuits reduction delay	15 Min			
N1 Outs. Temp. over 90 °C N5 Iegionella protection 5 °C N2 all HWS - difference temp. for HWS pump 1 °C N6 all HWS Residual heat several time N3 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C N4 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS 10 °C Q2 Acc. superelevation heat circuit set temp. 5 °C O8 Accumulator fill level reference temp. 75 °C Q2 Acc. superelevation heat circuit set temp. 5 °C O9 Accumulator HWS difference control ON Q3 Acc. superelevation HWS-set temp. 5 °C O1 External heat differential 2 °C Q4 Acc. switch difference HWS temp. 1 °C O11 External heat use until boiler temp. 65 °C Q4 Acc. difference temp. 5 °C O13 Acc. Residual heat use until boiler temp. 65 °C Q6 Acc. difference temp. 5 °C O13 Acc. Residual heat use until boiler temp.<			all HWS - hot water storage pump on at			all HWS - boiler superelevation	
N2 all HWS - difference temp. for HWS pump 1 °C N6 all HWS all HWS - balk sequent loading Residual heat several time N3 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS loading 10 °C N4 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS loading 10 °C 01 Acc. superelevation heat circuit set temp. 02 5 °C 08 Accumulator fill level reference temp. 02 75 °C 02 Acc. superelevation heat circuit set temp. 03 5 °C 09 Accumulator HWS difference control 04 0N 04 Acc. switch difference HWS temp. 05 1 °C 01 External heat differential 2 °C 2 °C 05 Acc. boiler-acc. base temperature 06 5 °C 013 Acc. Residual heat use until boiler temp. under 65 °C 07 Accumulator pump On - KT-Differential 5 °C 5 °C 013 Accumulator fill eval stemp. - change combustion 10 °C P2r Firebed-Set at ignition Wood chips 5 0 ° (65 °) P40 Flue gas tempe- ange combustion 10 °C <		N1	outs. temp. over	90 °C	N5	legionella protection	5 °C
N3 all HWS - hot water storage priority circuit factor 1 N7 all HWS - boiler superelevation at HWS loading 10 °C N4 all HWS - HWS pump after run time res. heat 5 °C V	SWF	N2	all HWS - difference temp. for HWS pump	1 °C	N6	all HWS	Residual heat several time
N4 all HWS - HWS pump after run time res. heat 5 °C Acc. 01 Acc. superelevation heat circuit set temp. 5 °C 08 Accumulator fill level reference temp. 75 °C 02 Acc. superelevation heat circuit set temp. 5 °C 09 Accumulator HWS difference control 0N 03 Acc. Superelevation HWS-Set temp. 5 °C 010 External heat switch on temp. 60 °C 04 Acc. switch difference HWS temp. 1 °C 011 External heat blockage time 15 Min 05 Acc. difference temp. 5 °C 013 Acc. Residual heat use until boiler temp. under 65 °C 06 Acc. difference temp. 5 °C 013 Acc. Residual heat use until boiler temp. under 65 °C 07 Accumulator pump On - KT-Differential 5 °C 013 Acc. 10 % P2r Firebed-Set at ignition Wood chips 50 ° (65 °) P40 Flue gas temp change combustion 100 °C P2s Firebed-Set at ignition ON 75 % P43 Time O2 Max at change to combustion 10 °C P3 Ex	- Z	N3	all HWS - hot water storage priority circuit factor	1	N7	all HWS - boiler superelevation at HWS loading	10 °C
Under01Acc. superelevation heat circuit set temp.5 °C08Accumulator fill level reference temp.75 °C02Acc. superelevation heat circuit set temp.5 °C09Accumulator HWS difference control0N03Acc. Superelevation HWS-Set temp.1 °C010External heat switch on temp.60 °C04Acc. switch difference HWS temp.1 °C011External heat differential2 °C05Acc. boiler-acc. base temperature58 °C012External heat blockage time15 Min06Acc. difference temp.5 °C013Acc. Residual heat use until boiler temp. under65 °C07Accumulator pump On - KT-Differential5 °C013Acc. Residual heat use until boiler temp. under65 °C07Accumulator pump On - KT-Differential5 °C013Acc. Residual heat use until boiler temp. under65 °C07Accumulator pump On - KT-Differential5 °C013Acc. Residual heat use until boiler temp. under65 °C7Accumulator pump On - KT-Differential5 °C013Acc. Residual heat use until boiler temp. under65 °C9P1Ignition time overrun15 MinP31Delta O2 Ignition off1 %92Firebed-Set at ignition Pollets42 ° (57 °)P41Flue gas tempe-ature rise30 °C93Exhaust fan max if ignition ON75 %P43Time O2 Max at change to combustion10 SecP3Exhaust fan max if ignition ON75 %P43Tim		N4	all HWS - HWS pump after run time res. heat	5 °C			
		01	Acc. superelevation heat circuit set temp	5 %	08	Accumulator fill level reference temp	75 °C
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		02	Acc. superelevation heat circuit set temp.	<u> </u>	09	Accumulator HWS difference control	0N
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	ator	03	Acc. Superelevation HWS-Set temp	<u> </u>	010	External heat switch on temp	0° 00
$ \mathbf{V} = \frac{1}{100}, \frac$	nulå	04	Acc. switch difference HWS temp	<u> </u>	010	External heat differential	2 °C
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	cur	05	Acc boiler-acc base temperature	58 °C	012	External heat blockage time	15 Min
P1 Ignition time overrun 15 Min P31 Delta O2 Ignition off 1 % P2r Firebed-Set at ignition Wood chips 50 ° (65 °) P40 Flue gas temp change combustion 100 °C P2s Firebed-Set at ignition Pellets 42 ° (57 °) P41 Flue gas temperature rise 30 °C P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superlevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation 5 ° <	0 - Ac	06	Acc. difference temp.	5 °C	012	Acc. Residual heat use until boiler temp.	65 °C
P1 Ignition time overrun 15 Min P31 Delta O2 Ignition off 1 % P2r Firebed-Set at ignition Wood chips 50 ° (65 °) P40 Flue gas temperature rise 30 °C P2s Firebed-Set at ignition Pellets 42 ° (57 °) P41 Flue gas temperature rise 30 °C P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation 5 ° P62 Interval for max. O2 decline 10 Sec		07	Accumulator pump On - KT-Differential	5 °C			
P1 Ignition time overrun 15 Min P31 Delta O2 Ignition off 1 % P2r Firebed-Set at ignition Wood chips 50 ° (65 °) P40 Flue gas temp change combustion 100 °C P2s Firebed-Set at ignition Pellets 42 ° (57 °) P41 Flue gas temperature rise 30 °C P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation 5 ° P61 Interval for max. O2 decline 10 Sec							
P2r Firebed-Set at ignition Wood chips 50 ° (65 °) P40 Flue gas temp change combustion 100 °C P2s Firebed-Set at ignition Pellets 42 ° (57 °) P41 Flue gas temperature rise 30 °C P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ionition on at		P1	Ignition time overrun	15 Min	P31	Delta O2 Ignition off	1 %
P2s Firebed-Set at ignition Pellets 42 ° (57 °) P41 Flue gas temperature rise 30 °C P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 19 % 19 % 10 Sec 10 Sec		P2r	Firebed-Set at ignition Wood chips	50 ° (65 °)	P40	Flue gas temp change combustion	100 °C
P2t Firebed-Set at ignition Misanthus loose 50 ° (65 °) P42 O2 Max at change to combustion 15 % P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 19 % 10 Sec 10 Sec 10 Sec		P2s	Firebed-Set at ignition Pellets	42 ° (57 °)	P41	Flue gas temperature rise	30 °C
P3 Exhaust fan max if ignition ON 75 % P43 Time O2 Max at change to combustion 10 Sec P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 19 % 10 Sec 10 Sec 10 Sec		P2t	Firebed-Set at ignition Misanthus loose	50 ° (65 °)	P42	O2 Max at change to combustion	15 %
P4 Neg. pressure set at ignition 105 Pa P44 Primary air at change to combustion 0 % P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 19 % 10 % 10 % 10 %		P3	Exhaust fan max if ignition ON	75 %	P43	Time O2 Max at change to combustion	10 Sec
P5 Hysteresis firebed-level 10 ° P50 Delivery rate for ignition at def. Firebed sensor (GBF) 40 % P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 19 % 10 % 10 % 10 %	ion	P4	Neg. pressure set at ignition	105 Pa	P44	Primary air at change to combustion	0 %
P6 Exhaust fan at kindling 100 % P51 Delivery time for ignition at def. Firebed sensor (GBF) 180 Sec P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 10 % 10 % 10 %	- Ignit	P5	Hysteresis firebed-level	10 °	P50	Delivery rate for ignition at def. Firebed sensor (GBF)	40 %
P10 second ignition attempt after 7 Min P60 max. O2 drop for Primary air flap close -0.2 % P11 Firebed sensor superelevation 5 ° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 9 10 Sec 10 Sec	٩	P6	Exhaust fan at kindling	100 %	P51	Delivery time for ignition at def. Firebed sensor (GBF)	180 Sec
P11 Firebed sensor superelevation 5° P61 Primary air flap CLOSED for 10 Sec P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 % 10 Sec 10 Sec		P10	second ignition attempt after	7 Min	P60	max. O2 drop for Primary air flap close	-0.2 %
P12 Neg. press. superelevation -10 Pa P62 Interval for max. O2 decline 10 Sec P30 Ignition on at Q2 > 19 %		P11	Firebed sensor superelevation	5 °	P61	Primary air flap CLOSED for	10 Sec
P30 Ignition on at $Q_2 > 19\%$		P12	Neg. press. superelevation	-10 Pa	P62	Interval for max. O2 decline	10 Sec
		P30	Ignition on at O2 >	19 %			



Menu		Description Factory Menu		Description	Factorv	
	Q0	Start de-ash	no	Q20s	Delay grate turn Pellets	20 Sec
	Q1	Min. run time combustion	60 Min	Q20t	Delay grate turn Miscanthus loose	0 Sec
	Q2r	Max. run time combustion Wood chips	240 (180) Min	Q21r	Grate rounds Wood chips	1
	Q2s	Max. run time combustion Pellets	300 Min	Q21s	Grate rounds Pellets	1
	Q2t	Max. run time combustion Miscanthus loose	120 Min	Q21t	Grate rounds Miscanthus loose	2
	Q3r	Burnout time wood chips	10 Min	Q22	Stop time for major de-ash	120 Min
	Q3s	Burnout time pellets	15Min	Q23r	Nr. of forced major de-ash cycles Wood	6
sh extraction		Demonstration and the second		000.	chips	40
	Q3t	Burnout time miscanthus loose	10 Min	Q23s	Nr. of forced major de-ash cycles Pellets	10
	Q4r	Exhaust fan max. at burnout wood chips	80 %	Q23t	Nr. of forced major de-ash cycles Miscanthus loose	1
Å -	Q4s	Exhaust fan max. at burnout pellets	80 %	Q25	max. motor current rotating grate	160 mA
a	Q4t	Exhaust fan max. at burnout miscanthus loose	80 %	Q26	Grate motor return run time	10 Sec
	Q10r	Ash initiator impulse wood chips	20	Q30	Grate opening	0 °
	Q10s	Ash initiator impulse pellets	14	Q50	Cleaning ash suction after de-ash	1x
	Q10t	Ash initiator impulse miscanthus loose	30	Q51r	Time ash suction wood chips	60 Sec
	Q11	max. motor current de-ash	2.5 A	Q51s	Time ash suction pellets	60 Sec
	Q12	Nominal motor current de-ash	1.2 A	Q51t	Time ash suction miscanthus loose	100 Sec
	Q20r	Delay grate turn wood chips	0 Sec	Q52	Exhaust fan at ash suction	30 %
	R1r	Stoker firebed set value wood chips	60 ° (75 °)	R41	Agitator nominal motor current RA (0.18kW Motor)	0.7 A
	R1s	Stoker firebed set value pellets	52 ° (67 °)	R41a	Agitator nominal motor current RA (0.25kW Motor)	1.2 A
	R1t	Stoker firebed set value miscanthus loose	60 ° (75 °)	R41b	Agitator nominal motor current RA-2 (0.18kW Motor)	0.7 A
	R2	Stoker time warning delivery rate	45 Min	R41c	Agitator nominal motor current RA-2 (0.25kW Motor)	1.2 A
	R10	Stoker max. motor current stoker	1.7 A	R42	Return time agitator	5 Sec
	R11	Stoker nominal motor current stoker	1.2 A	R50	max. motor current connection auger	1.7 A
	R13	Stoker max. return time stoker	5 Sec	R51	Nominal motor current conn. auger	1.2 A
atoi	R20r	Stoker - pulse wood chips	10 Sec	R52	Return time connection auger	10 Sec
- Stoker unit / Agita	R20s	Stoker - pulse pellets	30 Sec	R53r	Connection auger reduc. Connection auger - pulse wood chips	see list below
	R20t	Stoker - pulse miscanthus loose	10 Sec	R53s	Connection auger reduc.	see list below
	R30r	Agitator factor RA-delivery rate wood	see list below	R53t	Connection auger reduc.	see list below
₩	R30s	Agitator factor RA-delivery rate pellets	see list below	R60	Stoker red if firebed sensor over set	7 °
	11003	Agitator factor RA-delivery rate		1100		1
	R30t	miscanthus loose	see list below	R61	Stoker time overfill	30 Sec
	R40	Agitator max. motor current RA (0.18kW motor)	1.2 A	R62	Stoker delivery rate at overfill	70 %
	R40a	Agitator max. motor current RA (0.25kW motor)	1.6 A	R63	Stoker overfill-stop off if Firebed sensor set	0 °
	R40b	Agitator max. motor current RA-2 (0.18kW motor)	1.2 A	R64	Stoker delivery rate red. after overfill	90 %
	R40c	Agitator max. motor current RA-2 (0.25kW motor)	1.6 A			
	S1r	Lambda O2-Set value wood chips	7.00 (8.00) %	S3	Lambda CO2-Stop-difference	3.00 %
da-	S1s	Lambda O2-Set value pellets	8.00 %	S4	Lambda O2-increase part load	2,40 (1,40) %
Lambo ensor	S1t	Lambda O2-Set value miscanthus loose	8.50 %	S9	Lambda - exhaust fan at Lambda-calibration	60 %
S. L S.	S2	Lambda chimney sweep O2-Set value full load	6.00 %	S10	Lambda exhaust fan post run until O2 over	14.00 %



Menu		Description	Factory	Menu	Description					Factory	
	T1	Control - flue gas temperature minimum	100 °C	T30	Control - primary air (O2) Kp				4.5		
	T2	Control - flue gas temp. maximum	200 °C	T31	Control - p	rimary air (C	02) Tn			20	
	Т3	Control - Flue gas temp. Limiter Kp	1	T32	Control - p	Control - primary air (O2) Tv				5	
	T4	Control - Flue gas temp. Limiter Tn	250 Sec	T33	Control - F	Control - Primary air factor D-filter				2	
	T5	Control - Corr. Flue gas temp at 150 °C	-10 °C	T34	Control - F	ntrol - Primary air neg. boost				1	
	T10	Control - Boiler temp. controller Kp	2	T35	Control - E	Control - Boiler primary air maximum			100 %		
	T11	Control - Boiler temp. controller Tn	600 Sec	T36	Control - F	ontrol - Primary air def. lambda sensor		ensor		25 %	
	T12	Control - Boiler temp. controller Tv	100 Sec	T40	Control - n	ntrol - neg. press. controller Kp				0.1	
itrol	T13	Control - Boiler temp. controller T1	100	T41	Control - n	Control - neg. press. controller Tn			4 Sec		
	T14	Control - Boiler temp. Control - xw_exp	1.5	T42	Control - neg. press. controller Tv				0 Sec		
	T20	Control - delivery rate firebed Kp	1	T50	Exhaust fan Kp				65		
Cor	T21	Control - delivery rate firebed Tn	250 Sec	T51	Exhaust fan Tn				30 Sec		
, F	T22	Control - delivery rate firebed z	0	T60	Service sensor stoker grate offset (L)				-45		
	T23	Control - delivery rate firebed Min	0	T60a	Service sensor stoker grate offset (R)					45	
	T24	Control - delivery rate firebed Max	105	T61	Service sensor ash grate offset (L)					45	
	TOF	Control - delivery rate at def. Firebed	Α	Tete					45		
	125	sensor Kp	4	161a	Service se	Service sensor ash grate offset (R)			-45		
	TOP	Control - delivery rate at def. Firebed	100 500	Teo				100			
	120	sensor Tn	IZU Sec	162	Service sensor firebed offset (L)				190		
	T27	Control - delivery rate at def. Firebed	0	T620	Service co	nsor firebod	offset (D)		400		
	121	sensor Min	0	102a	Service sensor firebed offset (R)				190		
	T28	Control - delivery rate at def. Firebed	105								
	.20	sensor Max	100								
\	U1	Neg. press, NP set at 30% exhaust fan	25 (30) Pa	1120	Exhaust fan - motor type			F	C-Motor		
(dV	112	Neg. press, NP set at 80% exhaust fan	125 (150) Pa	1121	Exhaust fa	n control me	ax. RPM		<u>ــــــ</u>	3400	
s. (h fan	02	Neg press hoarder						3400			
res ust	U10	Warning/Error	50 %	U22	Exhaust fan speed tolerance				30 %		
g. p xhai	ļ								<u> </u>		
ЗШ	U11	Neg. press. time until error	30 Sec								
5											
									Cuptomor / last /		
	Z1	Boiler type	ECO-HKkV	VZ4	Load factory settings			Customer / Inst. /			
S									Service		
tior	Z1a	Boiler type	right / left	Z4a	Release load factory parameter file			Customer / Inst. /			
nnc	71h	Add function	not avail	75	Popot operation hours				Service		
al fu	714	RA Motor	0 18 L/M	77	Total reset						
Deci	710	RA-2 Motor	0.18 1/1/	772	Backup of boiler-ID						
- St	72	L oad parameters	Ves / no	78	Commission-No					y 00 / 110	
N	73	Save parameters	yes / no	79	Error list			ie	 at of errors		
	20		y037110								
Deres	vote	with different velues per func-						Eco			
		Boiler exhaust fan speed 100% output wood ching		60.9/	ZO 9/	PO 0/	55 0/	<u>20</u>	0/		
K3r	B0	Boiler exhaust fan speed 100% output wood chips			70 %	00 %	55 %	70	70 0/	00 % 20 0/	
N35 1/34	B0	Boller exhaust fan speed 100% output pellets				00 %	55 %	70	70 0/	70.9/	
NJI		Boller exnaust fan speed 100% output miscanthus			10	10	55 %	10	70	10 %	
	- Ke	Agitator factor DA delivery rate wood at inc			18	18			9	20	
R30r	Ag	Agitator factor RA-delivery rate wood chips			45 %	50 %	60 %	/0	% 85 % % 25 %		
R30s	Ag	Agitator factor RA-delivery rate pellets			13 %	15 %	19 %	21	%	25 %	
R30t		Agitator factor RA-delivery rate miscanthus loose			50 %	50 % 50 % 85 % 10		100	0 % 100 %		
R53r		Connection auger factor RA-delivery rate wood chips			45 %	50 %	60 %	/0	% 85 % % 25 %		
K53s		Connection auger factor RA-delivery rate pellets		12 %	13 %	15 %	19 %	21	%	25 %	
R53t	Co	Connection auger factor RA-delivery rate miscanthus loose			50 %	50 %	85 %	100)%	100 %	





Choose "Setup" menu

- D C press
- Choose,,Setup"

"Display-Settings":

- □ "01" Display Standby: deactivate or automatic
- □ "02" Display Standby after: (10 min. factory set.) ⇔Display switches in standby mode after set time
- "03" Display Backlight: Set the intensity of the backlight @from 100% - 10%

"Network":

- □ "04" Obtain IP address: manually or automatically
- F if setting <manually> is chosen, parameters "05 09" appear
- "010" NetBIOS Name: entered "Name" of the boiler in the network
 max. 15 letters

"GSM-Module":

- □ "020 022" GSM-dial number: saved numbers to which messages may be sent
 - @ if setting <manually> is chosen, parameters "05 09" appear

All data from the boiler and the combustion process will be saved in the boiler control memory. Additionally the data may be saved on the SD- Card inserted.

"Parameterdownload SD":

Save set parameters to SD-Card inserted

Press <Save parameters>

"Data recording SD":

Additional saving of latest boiler data to SD-Card

- Press <Start SD-Logging>
 - ✤ Logging of boiler data
 - To finish data logging
 - press <finish SD-Logging>

"Internal memory":

(Feature active during service level password confirmation) Save single boiler date to SD-Card

- Choose data
- □ Press <Copy>
 - ♦ copy the records to the SD-Card

6.1 Reset parameters to factory settings

No. Z4 Load factory set	tings
NO	
YES	

D construction press

Choose "Service"

Choose "Z-Special features" menu

- Choose "No Z4 Load factory settings."

6.2 Save / load latest parameter file control internal

No. 23 Load parameter set
NO
YES
No. Z2 Load parameters
NO
YES

To save latest parameters For example: prior any changes

For reloading of saved parameters



Chapter XI: Appendix



Please be advised that we are not responsible for damages or malfunctions resulting from non-observance of the operation manual.

notice

7 Copyright notice

This manual should be kept confidential. The manual is intended solely to be used by authorised persons.

The transfer to third parties is prohibited and is liable to compensation. All rights reserved, also translations.

No part of this manual may be reproduced or processed using electronic systems, duplicated or distributed without permission of Hargassner GmbH.

7.1 Special measures prior commissioning through the operator

Licensing requirements for safe operation and accident prevention regulations must be observed!

7.2 Liability

The AUTOMATIC BIOMASS BOILER is a state-of-the-art product and manufactured and tested according to recognised safety regulations. However, improper use may cause lethal hazards for the operator or third parties or may damage the unit and other property.

The AUTOMATIC BIOMASS BOILER must only be operated as intended and in technically perfect condition! Especially, errors tending to affect the safety shall be cleared immediately!

The liability for the function of the AUTOMATIC BIOMASS BOILER must be borne by the owner or user, if the device has been used by persons without the necessary knowledge from Hargassner GmbH, the device has been improperly used, serviced or repaired or has been handled in a manner that does not conform to proper use.

In the interest of the continuous development and improvement of our products, we reserve all rights to make technical changes to the information contained in our printed material. Changes, errors and printer's errors do not justify claims for damages.

Only Original- Hargassner- spare parts must be used.

In addition to the guidelines in this operation manual, please follow general guidelines for safety and accident prevention. The AUTOMATIC BIOMASS BOILER must at least 15 minutes prior be separated from the mains prior any maintenance works on the boiler (Service, unscrew covers, etc.) Hargassner GmbH shall not be liable for direct or consequential damage resulting from failure to observe the technical instructions, guidelines and recommendations. The vast experience of latest production technology and highest quality standards from **Hargassner GmbH** guarantee the reliability of this boiler system. **Hargassner GmbH** can under no circumstances be held liable for improper operation of the product, for damage to the product itself or for consequential damage caused by the product if the damage has been caused by incorrect use or handling of the product.

The customer has NO warranty claims:

- if heating fuel is missing wrong or of poor quality
- if damages occur through incorrect assembly, misuse or lack of maintenance
- if the installation manual and operation manual is NOT observed
- for defects that do not affect the performance of the system. E.g.: Paint defects,....
- for damages arising from force majeure like fire, flooding, lightning stroke, electrical surge, power loss, ...
- if a non-licensed installer or non-licensed plumber installs the product
- for damages arising through air pollution, very dusty surrounding, aggressive vapours, corrosion through oxygen (non diffusion-resistant plastic tubing), installation in inappropriate rooms (laundry room,) or through further use, even though a defect has been recognised.

For the correct reparation, maintenance and service, or any other error not mentioned in this manual, **Hargassner GmbH** has to be contacted prior any works on the plant.

Warranty and liability of the general terms and conditions of **Hargassner GmbH** are not to be extended because of hints pointed out in this manual.

The **safety instructions** in this manual must be observed. Only use **Hargassner GmbH** - spare parts or **Hargassner GmbH** released, equivalent spare parts. Constant technical innovations mean that we reserve the right to modify the design of our products and services without notice.

For any questions always prepare the Hargassner Boiler number .

We wish you the best with your BIOMASS BOILER.

